# FLIP-OPEN OBJECTIVE LENS COVERS - OBJECTIVE LENS COVER #51 2.575" (65.4MM)

## Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.

## Attributes

- Name: OBJECTIVE LENS COVER #51 2.575" (65.4MM)
- Manufacturer: BUTLER CREEK
- Product no.: 749001527
- Mfr. No.: 30510
- Color: Black
- End Fit: Objective
- Model Number: 2.575'' (65.4MM)
- Size: 2.575
- Delivery weight: 0.045kg
- Shipping height: 8mm
- Shipping width: 94mm
- Shipping length: 150mm
- UPC: 051525305101

# Table of Contents

# FLIPOPEN OBJECTIVE LENS COVERS Safety Instructions

## Introduction

Thank you for choosing the FLIPOPEN OBJECTIVE LENS COVERS, OBJECTIVE LENS COVER #51 2.575" (65.4MM). These covers are designed to protect your scope's lenses from weather, dust, and moisture during tactical and hunting situations. This safety instruction guide provides essential information to ensure safe use and maintenance of your product in compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Always ensure that the lens cover is properly secured to avoid accidental loss or damage.
- Regularly inspect the lens cover for any signs of wear or damage. Replace if necessary.
- Keep the lens covers out of reach of children to prevent accidental injury or misuse.
- Be aware of your surroundings when using your scope to avoid hazards that may not be related to the product itself.
- Report any unsafe conditions or accidents related to the product to local authorities.

## Specific Safety Precautions for Use

- Do not force the cover open or closed. Use gentle finger pressure to operate the flipopen mechanism.
- Avoid using the lens covers in extreme temperatures or conditions that may compromise their integrity.
- Ensure that the covers are dry and clean before storing or using them to maintain optimal performance.
- If the lens cover becomes damaged, discontinue use immediately and seek a replacement.

## Instructions for Installation and Usage

1. **Measuring Your Scope:**

   - To determine the correct lens cover size, measure the diameter of your scope eyepiece or objective.
   - Refer to the provided size chart to select the appropriate lens cover.

2. **Installing the Lens Cover:**

   - Align the cover with the eyepiece or objective of your scope.
   - Gently press the cover onto the lens until it fits securely.
   - Ensure there is no gap between the cover and the lens to prevent dust and moisture intrusion.

3. **Using the Lens Cover:**

   - To open the lens cover, apply gentle finger pressure to the designated area. The cover will spring open for easy access.
   - When not in use, ensure the cover is closed to protect the lens from environmental factors.

4. **Cleaning and Maintenance:**

   - Clean the lens cover with a soft, dry cloth to remove dust or debris.
   - Avoid using harsh chemicals or abrasive materials that may damage the cover.

# Disposal Instructions

- Dispose of the lens cover in accordance with local waste disposal regulations.
- If the cover is damaged beyond repair, consider recycling materials where possible to minimize environmental impact.

# Contact Information for Further Support

For any questions or concerns regarding the FLIPOPEN OBJECTIVE LENS COVERS, please refer to the product packaging for contact details and support resources.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy using your FLIPOPEN OBJECTIVE LENS COVERS responsibly!

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](www.brownells.at)