

Buttstock LOP Spacers - MDT Accessories - Length of Pull Spacer - BLK

[Rifle Parts](#) > [Stock Parts](#) > [Butt Plate Parts](#) > [Buttstock Spacers](#)

Add an extra inch to your MDT butt stock with a 1" aluminum extender. Simple installation fits the extender between your butt pad and pad plate.

NO IMAGE
AVAILABLE

Attributes

- Name: [MDT Accessories - Length of Pull Spacer - BLK](#)
- Manufacturer: [MDT](#)
- Product no.: EU2004405
- Mfr. No.: 103938-BLK
- Colour: Black
- Material: Aluminum
- Delivery weight: 0.2kg
- Shipping height: 44mm
- Shipping width: 95mm
- Shipping length: 194mm
- UPC: 709951108048

Table of Contents

- [Startpage](#)
- [MDT Buttstock LOP Spacers Safety Instruction Guide](#)
- [About Us](#)

MDT Buttstock LOP Spacers Safety Instruction Guide

Introduction

Thank you for choosing the MDT Buttstock LOP Spacers. This product is designed to enhance your shooting experience by providing an additional inch of length to your MDT buttstock. To ensure your safety and the proper use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always inspect the product for any damage or defects before use.
- Ensure that the spacer is compatible with your specific MDT buttstock model.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform regularly.

Specific Safety Precautions for Use

- Do not use the spacer if it shows signs of wear or damage.
- Ensure that all components are securely fastened before using the buttstock.
- Avoid using the product in extreme weather conditions that may affect the integrity of the materials.
- If you are inexperienced with firearm accessories, seek guidance from a qualified professional before installation.

Instructions for Installation and Usage

1. **Gather Required Tools:** You will need a screwdriver to complete the installation.
2. **Preparation:**
 - Ensure your firearm is unloaded and in a safe condition.
 - Remove the butt pad from your MDT buttstock by unscrewing it carefully.
3. **Install the Spacer:**
 - Place the aluminum extender between the butt pad and the pad plate.
 - Align the holes of the extender with those of the pad plate.
 - Securely fasten the butt pad back onto the stock using the screws.
4. **Final Check:**
 - Ensure that the spacer is firmly in place and that there is no movement.
 - Conduct a safety check to confirm that the firearm is functioning correctly with the new configuration.
5. **Usage:**
 - Test the adjustment by shouldering the firearm to ensure comfort and proper fit.
 - Make any necessary adjustments before engaging in shooting activities.

Disposal Instructions

- Dispose of the product responsibly according to local regulations.
- Do not throw the product in regular household waste.
- If the product is damaged or no longer needed, consider recycling the materials where applicable.

Contact Information for Further Support

For any questions or concerns regarding the MDT Buttstock LOP Spacers, please refer to the manufacturer's contact information provided with your product packaging or visit the manufacturer's website for additional

resources.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk