

AR-15/M16 FORWARD ASSIST SPRINGS - BROWNELLS BRN AR-15 FORWARD ASSIST SPRING, CHROME SILICON, 3 PACK

[Rifle Parts](#) > [Receiver Parts](#) > [Forward Assist Parts](#)

Put the zing back into the rifle you thought was past its prime. Manufactured to precise tolerances, these high quality, replacement springs help keep your AR-15 functioning properly. Great for emergency spares or for assembling a parts rifle. Available singly, or in 3-paks.



Attributes

- Name: [BROWNELLS BRN AR-15 FORWARD ASSIST SPRING, CHROME SILICON, 3 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000080
- Mfr. No.:
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806003330

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AR15/M16 Forward Assist Springs
- About Us

Safety Instruction Guide for AR15/M16 Forward Assist Springs

Introduction

Thank you for choosing the AR15/M16 Forward Assist Springs from Brownells. This guide provides essential safety instructions and guidelines to ensure the proper use and handling of your product. Please read this document carefully to maximize your safety and the performance of your rifle.

General Safety Guidelines

- Always handle firearms with care and follow all safety protocols.
- Ensure that your AR15 is unloaded before performing any maintenance or installation.
- Keep the springs out of reach of children and other vulnerable individuals.
- Regularly inspect your firearm and its components for wear and damage.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use only the specified replacement springs designed for your AR15 model.
- Ensure that all installation is done in a clean and dry environment to prevent contamination.
- Wear safety glasses during installation to protect your eyes from potential spring release.
- Avoid using excessive force when installing the springs to prevent damage to components.
- Do not modify the springs or any other components of your firearm.

Instructions for Installation and Usage

1. Preparation

- Ensure your AR15 is completely unloaded.
- Gather necessary tools: a small punch tool and a hammer.
- Work in a welllit area.

2. Removing the Old Springs

- Use the punch tool to carefully remove the existing forward assist springs from the rifle.
- Take care not to damage surrounding components during removal.

3. Installing the New Springs

- Align the new forward assist spring with the appropriate mounting point.
- Gently press the spring into place using the punch tool, ensuring it is seated properly.
- Confirm that the spring is securely in position before reassembling your rifle.

4. Final Checks

- After installation, reassemble your rifle and perform a function check to ensure proper operation.
- Test the forward assist mechanism to confirm it is functioning smoothly.

Disposal Instructions

- Dispose of old springs and any packaging materials according to local regulations.
- Do not discard springs in a manner that could pose a risk to the environment or public safety.

Contact Information for Further Support

For any inquiries or support regarding the AR15/M16 Forward Assist Springs, please refer to the product packaging for contact information or visit the manufacturer's website.

By following these guidelines, you can ensure the safe use and longevity of your AR15/M16 Forward Assist Springs. Always prioritize safety and consult professionals if you have any doubts about installation or usage. Thank you for your commitment to responsible firearm ownership.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk