

M16 BURST CLUTCH SPRING - BROWNELLS M16 CLUTCH SPRING 3 PACK

[Rifle Parts](#) > [Receiver Parts](#) > [Receiver Hardware](#) > [Springs](#)

Put the zing back into the rifle you thought was past its prime. Manufactured to precise tolerances, these high quality, replacement springs help keep your AR-15 functioning properly. Great for emergency spares or for assembling a parts rifle. Available singly, or in 3-paks.



Attributes

- Name: [BROWNELLS M16 CLUTCH SPRING 3 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000092
- Mfr. No.:
- Weapon type: AR-15
- Quantity: 3
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [M16 Burst Clutch Spring Safety Instruction Guide](#)
- [About Us](#)

M16 Burst Clutch Spring Safety Instruction Guide

Introduction

Thank you for choosing the M16 Burst Clutch Spring from Brownells. This guide provides essential safety information and instructions for the proper use, installation, and disposal of the product. Please read this guide carefully to ensure safe and effective use of the clutch spring.

General Safety Guidelines

- Ensure that the product is suitable for your specific AR15 model before use.
- Always handle the clutch spring with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the clutch spring for signs of wear or damage before use.
- If you experience any issues or notice any defects, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when handling or installing the clutch spring.
- Ensure the rifle is unloaded and the chamber is clear before attempting any installation or maintenance.
- Follow the manufacturer's instructions closely to avoid improper installation which could lead to malfunctions.
- Do not exceed the recommended specifications for use as outlined by the manufacturer.
- Be aware of your surroundings and ensure a safe environment when working with firearms.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and safety equipment.
- Ensure that your work area is clean and free of distractions.

2. Installation:

- Ensure the rifle is unloaded and the chamber is clear.
- Remove the existing clutch spring if applicable, following the manufacturer's guidelines.
- Carefully install the new M16 Burst Clutch Spring:
 - Align the spring with the designated area in the rifle.
 - Gently press into place, ensuring it is seated correctly.
- Doublecheck the installation to confirm that the spring is secure.

3. Usage:

- After installation, conduct a function check to ensure proper operation.
- If any issues arise during use, cease operation immediately and inspect the installation.

Disposal Instructions

- Dispose of any damaged or worn clutch springs in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding the safety and use of the M16 Burst Clutch Spring, please refer to the contact information provided by the retailer or manufacturer.

Conclusion

By following these safety instructions and guidelines, you can ensure the safe and effective use of the M16 Burst Clutch Spring. Always prioritize safety and remain informed about best practices in firearm maintenance. Thank you for your commitment to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk