

BRN-180™ SPRING KIT - BROWNELLS BRN-180 GEN 1/2 SPRING KIT

[Rifle Parts](#) > [Receiver Parts](#) > [Receiver Hardware](#) > [Springs](#)

Replacement or Backup Spring Kit for the BRN-180™ Upper Receiver. Includes essential Springs. Gen1 and Gen2. 2x Recoil Springs 1x Bolt Return Spring 1x Piston Drive Rod Spring



Attributes

- Name: [BROWNELLS BRN-180 GEN 1/2 SPRING KIT](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000611
- Mfr. No.: 1B180SK
- Model: BRN-180
- Weapon type: Brownells
- Delivery weight: 0.227kg
- Shipping height: 13mm
- Shipping width: 102mm
- Shipping length: 229mm
- UPC: 050806003989

Item details

Made in USA

Table of Contents

- Startpage
- BRN180™ Spring Kit Safety Instructions
- About Us

BRN180™ Spring Kit Safety Instructions

Introduction

Thank you for choosing the BRN180™ Spring Kit by Brownells. This kit is designed as a replacement or backup for the BRN180™ Upper Receiver and includes essential springs for both Gen 1 and Gen 2 models. Please read and follow these safety instructions carefully to ensure safe and effective use of this product.

General Safety Guidelines

- Ensure that you are familiar with the operation and handling of firearms before using this product.
- Always handle springs and other components with care to avoid injury.
- Store the spring kit in a safe, dry place away from children and unauthorized users.
- Regularly inspect the springs for wear and damage before each use.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear safety glasses when handling or installing springs to protect your eyes from potential injury.
- Avoid using excessive force when installing or removing springs to prevent damage to the components.
- Ensure that the firearm is unloaded and pointed in a safe direction before beginning any installation or maintenance work.
- Keep hands clear of moving parts during installation to prevent pinching or injury.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and the BRN180™ Spring Kit components.
- Ensure that the firearm is unloaded and in a safe condition.

2. Installation of Springs

- **Recoil Springs:**
 - Locate the recoil spring assembly in your BRN180™ Upper Receiver.
 - Remove the old recoil springs and replace them with the new ones from the kit.
 - Ensure that the springs are seated correctly and securely.
- **Bolt Return Spring:**
 - Identify the bolt return spring compartment.
 - Remove the old spring and install the new bolt return spring, ensuring proper alignment.
- **Piston Drive Rod Spring:**
 - Access the piston drive rod area.
 - Replace the old piston drive rod spring with the new one, ensuring it is properly positioned.

3. Final Checks

- After installation, doublecheck that all springs are installed correctly and securely.
- Conduct a function check of the firearm to ensure proper operation.

Disposal Instructions

- Dispose of old springs and any packaging materials in accordance with local regulations.
- Do not dispose of springs in a manner that could pose a hazard to others.

Contact Information for Further Support

For any inquiries or concerns regarding the BRN180™ Spring Kit, please refer to the contact details provided by the manufacturer or consult your local regulations for safety inquiries.

By following these safety instructions, you will help ensure a safe and effective experience with your BRN180™ Spring Kit. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk