

REPLACEMENT SLIDE PARTS FOR GLOCK® 43/43X/48 - BROWNELLS BRN SLIDE PARTS KIT FOR GLOCK 43/43X/48

[Home](#)

Contains all the parts you need to complete the innards of an aftermarket slide or refurbish a factory slide to like-new standards. All the parts in our Glock 43/43x/48 Slide Parts Kit are aftermarket parts made to the correct dimensions for proper fit, finish, and function in a factory spec slide. The extractor and firing pin are made from cast 17-4 SS. The extractor depressor plunger and firing pin safety are machined from bar stock. Kit Includes: Extractor Extractor Depressor Plunger Extractor Depressor Plunger Spring Spring -Loaded Bearing Slide Cover Plate Firing Pin Spacer Sleeve Firing Pin Spring Spring Cups Firing Pin Safety Firing Pin Safety Spring Guide Rod and Recoil Spring Assembly



Attributes

- Name: [BROWNELLS BRN SLIDE PARTS KIT FOR GLOCK 43/43X/48](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078000635
- Mfr. No.: 02-2004-02-00
- Model: 48,43,43X
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 10mm
- Shipping length: 18mm
- UPC: 050806500907

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for Replacement Slide Parts for Glock® 43/43X/48](#)
- [About Us](#)

Safety Instruction Guide for Replacement Slide Parts for Glock® 43/43X/48

Introduction

Thank you for choosing the Replacement Slide Parts for Glock® 43/43X/48 from Brownells. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of the product. Please read this manual carefully before use.

General Safety Guidelines

- Ensure that all parts are compatible with your Glock® model before installation.
- Always handle firearms and firearm parts with care and in accordance with safety protocols.
- Keep all components out of reach of children and unauthorized users.
- Regularly inspect parts for wear and damage before use.
- Do not attempt to modify or alter any parts, as this may compromise safety and functionality.
- Always follow local laws and regulations regarding firearm ownership and modifications.

Specific Safety Precautions for Use

- Only use this product with Glock® 43, 43X, or 48 models.
- Ensure the firearm is unloaded before beginning any installation or maintenance procedures.
- Use appropriate tools and safety gear when handling parts.
- Be aware of potential hazards, including sharp edges and small components that may pose a choking hazard.
- If you experience any issues during installation or use, cease operation immediately and seek professional assistance.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools and components.
- Ensure you are in a welllit and organized workspace.

2. Disassembly of the Slide

- Follow the manufacturer's instructions for disassembling your Glock® slide.
- Carefully remove the existing parts that will be replaced.

3. Installation of New Parts

- **Extractor:** Install the extractor by aligning it correctly in the slide.
- **Extractor Depressor Plunger:** Insert the extractor depressor plunger into its designated slot.
- **Extractor Depressor Plunger Spring:** Place the spring in position to ensure proper tension.
- **SpringLoaded Bearing:** Install as per the specifications.
- **Slide Cover Plate:** Attach securely to the rear of the slide.
- **Firing Pin Spacer Sleeve:** Insert the spacer sleeve into the firing pin channel.
- **Firing Pin Spring:** Install the firing pin spring ensuring it is seated correctly.
- **Spring Cups:** Place spring cups in their respective positions.
- **Firing Pin Safety:** Install the firing pin safety ensuring it functions correctly.
- **Firing Pin Safety Spring:** Insert the spring as specified.
- **Guide Rod and Recoil Spring Assembly:** Reassemble the guide rod and recoil spring.

4. Reassembly of the Slide

- Once all new parts are installed, reassemble the slide according to the manufacturer's guidelines.
- Ensure all components are securely fitted and functioning properly.

5. Final Inspection

- Conduct a thorough inspection of the slide and all installed parts.
- Confirm that everything is properly aligned and secured before using the firearm.

Disposal Instructions

- Dispose of any old or unused parts in accordance with local regulations.
- Do not throw parts in regular household waste; consider recycling where possible.
- Ensure that any hazardous materials are disposed of safely and responsibly.

Contact Information for Further Support

For questions or concerns regarding the Replacement Slide Parts for Glock® 43/43X/48, please refer to the manufacturer's website or customer service for assistance.

Thank you for your attention to these safety instructions. Your safety and the safety of others depend on your responsible handling and use of this product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk