

AR-15 SEAR SPRINGS - BROWNELLS AR-15 AUTO SEAR SPRING

[Rifle Parts](#) > [Triggers Parts](#) > [Sear Parts](#) > [Sear Springs](#)

Put the zing back into the rifle you thought was past its prime. Manufactured to precise tolerances, these high quality, replacement springs help keep your AR-15 functioning properly. Great for emergency spares or for assembling a parts rifle. Available singly, or in 3-paks.



Attributes

- Name: [BROWNELLS AR-15 AUTO SEAR SPRING](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078101114
- Mfr. No.:
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- AR15 SEAR SPRINGS BROWNELLS AR15 AUTO SEAR SPRING Safety Instruction Guide
- About Us

AR15 SEAR SPRINGS BROWNELLS AR15 AUTO SEAR SPRING Safety Instruction Guide

Introduction

Thank you for choosing the AR15 SEAR SPRINGS by Brownells. This guide is designed to ensure the safe use and proper handling of your product. Please read this document carefully to understand the safety guidelines, installation instructions, and disposal methods. Your safety is our priority.

General Safety Guidelines

- Ensure that the product is suitable for your specific AR15 model before use.
- Always handle firearms and firearm components with care and follow standard safety practices.
- Store the springs in a dry, cool place away from direct sunlight and moisture.
- Regularly check for wear and tear on the springs and replace them if necessary.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use these springs in firearms that are compatible with AR15 components.
- Keep the springs out of reach of children and unauthorized users.
- Always wear appropriate safety gear, such as eye protection, when handling or installing firearm components.
- Be aware of your surroundings and ensure that the area is safe for firearm handling.
- Do not attempt to modify or alter the springs, as this may compromise safety.

Instructions for Installation and Usage

1. Preparation

- Ensure your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a punch and hammer.

2. Installation Steps

- Remove the existing sear spring from the AR15 if applicable.
- Align the new AR15 sear spring with the designated area in the firearm.
- Use the punch and hammer to gently secure the spring in place, ensuring it is seated properly.
- Doublecheck that the spring is installed correctly and is functioning as intended.

3. PostInstallation Check

- After installation, perform a function check to ensure the firearm operates safely.
- Test the trigger mechanism to confirm that it engages and releases properly.

Disposal Instructions

- Dispose of any old or damaged springs in accordance with local regulations.
- Do not dispose of springs in regular household waste.
- Consider recycling options for metal components when applicable.

Contact Information for Further Support

For any questions or concerns regarding the AR15 SEAR SPRINGS or safety issues, please reach out to your local dealer or manufacturer's representative. It is important to have access to reliable information and support for your product.

Conclusion

By following these safety instructions, you can ensure the proper use and longevity of your AR15 SEAR SPRINGS. Always prioritize safety and stay informed about the best practices for firearm maintenance and handling. Thank you for your attention to these important safety guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk