

AR-15 DISCONNECTOR SPRINGS - BROWNELLS BRN AR-15 FCG DISCONNECTOR SPRING

[Rifle Parts](#) > [Triggers Parts](#) > [Disconnecter Parts](#) > [Disconnecter Springs](#)

AR-15 DISCONNECTOR SPRINGS Put the zing back into the rifle you thought was past its prime. Manufactured to precise tolerances, these high quality, replacement springs help keep your AR-15 functioning properly. Great for emergency spares or for assembling a parts rifle. Available singly, or in 3-paks. SPECIFICATIONS: Materials and Finish at least equal to OEM parts Universal AR-15



Attributes

- Name: [BROWNELLS BRN AR-15 FCG DISCONNECTOR SPRING](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 078101120
- Mfr. No.:
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806004641

Item details

Made in USA

Table of Contents

- Startpage
- AR15 Disconnector Spring Safety Instruction Guide
- About Us

AR15 Disconnector Spring Safety Instruction Guide

Introduction

Thank you for choosing the AR15 Disconnector Spring from Brownells. This guide provides essential safety instructions and information for the proper use and maintenance of your disconnector springs. Please read this guide carefully to ensure safe and effective operation.

General Safety Guidelines

- Ensure that the product is used in accordance with all applicable laws and regulations.
- Always inspect the product for damage or wear before installation and use.
- Keep the springs out of reach of children and unauthorized users.
- Do not modify or alter the springs in any way, as this may compromise their performance and safety.
- Report any unsafe products or incidents to appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when handling or installing the disconnector springs.
- Handle the springs with care to avoid injury from sharp edges or potential snapback during installation.
- Ensure your firearm is unloaded and safe before beginning any installation or maintenance work.
- Follow all manufacturer guidelines for the assembly and disassembly of your AR15 to avoid injury.

Instructions for Installation and Usage

1. Preparation:

- Ensure your workspace is clean and welllit.
- Gather all necessary tools and materials for the installation.

2. Installation Steps:

- Unload your AR15 and ensure it is safe to work on.
- Remove the existing disconnector spring if applicable.
- Carefully install the new disconnector spring by following these steps:
 - Align the spring correctly in the disconnector assembly.
 - Ensure that the spring is seated properly to prevent malfunctions.
- Reassemble the firearm according to the manufacturer's instructions.

3. PostInstallation:

- Conduct a thorough function check of your firearm to ensure proper operation.
- If any issues arise during the function check, consult a qualified gunsmith.

Disposal Instructions

- Dispose of any old or damaged springs in accordance with local regulations.
- Do not throw springs in regular household waste; instead, consider recycling options where available.

Contact Information for Further Support

For any inquiries or concerns regarding the AR15 Disconnector Spring, please reach out to the designated support channels provided with your product packaging or purchase confirmation.

Thank you for your attention to these safety instructions. Proper handling and installation of your AR15 disconnector springs will ensure a safe and enjoyable shooting experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk