


SW-MS-222 MAINSPRING FOR S&W K,L,N FRAME REVOLVER - BROWNELL'S SW-MS-22 REDUCED POWER MAINSPRING S&W K, L, N FRAME 10PK

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainsprings](#)

"Guaranteed Superior"

Lighter than stock Power Rib mainspring. 1 spring or 10 spring packages.



Attributes

- Name: [BROWNELL'S SW-MS-22 REDUCED POWER MAINSPRING S&W K, L, N FRAME 10PK](#)
- Manufacturer: [BROWNELL'S](#)
- Product no.: 080665211
- Mfr. No.:
- Model: K Frame,L Frame,N Frame
- Weapon type: Smith & Wesson
- Delivery weight: 0.136kg
- Shipping height: 10mm
- Shipping width: 81mm
- Shipping length: 163mm
- UPC: 050806101920

Item details

Made in USA

Table of Contents

- Startpage
- SWMS222 Mainspring Safety Instruction Guide
- About Us

SWMS222 Mainspring Safety Instruction Guide

Introduction

Thank you for choosing the SWMS222 Mainspring for S&W K, L, N Frame Revolvers. This guide provides important safety information and instructions to ensure the safe use of this product. Please read this manual carefully before installation and usage.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Keep the mainspring and all related components out of reach of children and vulnerable individuals.
- Regularly inspect the mainspring for wear or damage before use.
- Follow all local laws and regulations regarding firearms and their components.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always handle firearms with care and treat every firearm as if it is loaded.
- When installing or replacing the mainspring, ensure the firearm is unloaded and pointed in a safe direction.
- Use proper tools and wear safety glasses to protect your eyes during installation.
- Do not modify the mainspring or any other firearm components, as this may lead to unsafe conditions.
- If you are not familiar with firearm maintenance, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation

- Ensure you have the necessary tools: a flathead screwdriver, a punch tool, and safety glasses.
- Make sure the firearm is unloaded and pointed in a safe direction.

2. Removing the Old Mainspring

- Open the firearm and verify it is empty.
- Remove the side plate according to the manufacturer's instructions.
- Carefully remove the old mainspring using the punch tool to release it from its housing.

3. Installing the New Mainspring

- Take the new SWMS222 mainspring from its packaging.
- Align the mainspring with the housing and gently press it into place.
- Ensure it is securely seated before reassembling the firearm.

4. Reassembling the Firearm

- Replace the side plate, ensuring all components are correctly aligned.
- Check the functionality of the mainspring by performing a dry fire test (without ammunition) to ensure proper operation.

5. Final Safety Check

- After installation, conduct a thorough safety check.
- Ensure the firearm is functioning correctly and safely before use.

Disposal Instructions

- Dispose of the old mainspring and any packaging materials in accordance with local regulations.
- Do not dispose of the mainspring in regular household waste if it is considered hazardous.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries or additional support regarding the SWMS222 mainspring, please refer to the manufacturer's contact information included in the product packaging.

Thank you for your attention to these safety instructions. Enjoy your experience with the SWMS222 Mainspring for S&W K, L, N Frame Revolvers.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk