

SW-MS-223 MAINSPRING FOR S&W K,L,N FRAME REVOLVER - SW-MS-223 STANDARD MAINSPRING FOR S&W K, L, N FRAME

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainsprings](#)

"Guaranteed Superior"

Power Rib mainspring that duplicates the factory spring's rate. 1 spring packages.



Attributes

- Name: [SW-MS-223 STANDARD MAINSPRING FOR S&W K, L, N FRAME](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080665220
- Mfr. No.:
- Make: Smith & Wesson
- Model: K Frame,L Frame,N Frame
- Delivery weight: 0.011kg
- Shipping height: 8mm
- Shipping width: 79mm
- Shipping length: 173mm
- UPC: 050806101937

Item details

Made in USA

Table of Contents

- Startpage
- SWMS223 Mainspring Safety Instruction Guide
- About Us

SWMS223 Mainspring Safety Instruction Guide

Introduction

Thank you for choosing the SWMS223 Mainspring for your Smith & Wesson K, L, and N Frame Revolver. This guide provides essential safety instructions to ensure the proper use and handling of this product. Please read this guide carefully before using the mainspring.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified in the product description.
- Always inspect the mainspring for any signs of damage or wear before installation.
- Keep this product out of reach of children and unauthorized users.
- If you are unsure about any aspect of using this product, consult a qualified gunsmith or firearms expert.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Installation Precautions:**
 - Always wear safety glasses when handling or installing the mainspring.
 - Ensure the firearm is unloaded before attempting to install or replace the mainspring.
- **Usage Precautions:**
 - Do not attempt to modify the mainspring in any way.
 - Only use this mainspring with compatible Smith & Wesson K, L, and N Frame Revolvers.
- **Storage Precautions:**
 - Store the mainspring in a cool, dry place away from direct sunlight and moisture.
 - Keep the mainspring in its original packaging or a secure container when not in use.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools such as a screwdriver and a punch tool for installation.

2. Installation Steps:

- Remove the revolver's side plate according to the manufacturer's instructions.
- Carefully remove the old mainspring, taking note of its orientation.
- Install the SWMS223 mainspring in the same orientation as the old spring.
- Reassemble the side plate securely, ensuring all screws are tightened properly.

3. Usage:

- Once installed, test the revolver's action to ensure smooth operation.
- If you notice any unusual resistance or malfunction, consult a qualified gunsmith immediately.

Disposal Instructions

- Dispose of the old mainspring and any packaging materials in accordance with local regulations.
- Do not dispose of the mainspring in household waste. Check with local waste management for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the SWMS223 Mainspring, please consult your local firearms dealer or a qualified gunsmith. They can provide you with the necessary support and guidance.

Thank you for prioritizing safety while using the SWMS223 Mainspring. Your adherence to these guidelines helps ensure a safe and enjoyable experience with your Smith & Wesson revolver.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at