

ROLL PIN HOLDERS - BROWNEllS ROLL PIN HOLDER #1, 1/16" (1.6MM)

[Gunsmith Tools](#) > [General Gunsmith Tools](#) > [Punches](#)

Hollow-Ended "Starter" Punches For Roll Pins

ROLL PIN HOLDERS The Brownells Roll Pin Holders are precision-engineered tools designed to securely hold roll pins in perfect alignment during firearm assembly or maintenance, ensuring accurate and damage-free installation. These holders are particularly beneficial for handling small, hard-to-grasp pins or those situated in tight spaces. Available Sizes and Specifications: The Roll Pin Holders are available individually or as a complete 5-piece set, accommodating various pin sizes commonly encountered in firearms: #1 - 1/16" (1.6mm): Notched to clear M16/AR-15 rear sights, facilitating easier installation in these specific models. #2 - 5/64" (2.0mm): Ideal for slightly larger pins, providing a secure hold during installation. #3 - 3/32" (2.4mm): Suitable for medium-sized pins, ensuring precise alignment. #4 - 1/8" (3.2mm): Designed for larger pins, maintaining stability during insertion. #5 - 3.5mm (0.138"): Excellent for holding the pin that retains the breech block on Sig handguns. Each holder is made from high-quality steel, ensuring durability and longevity. After the pin is properly started using the holder, it is recommended to finish driving it in with a roll pin punch for optimal results. Product Variations: Brownells offers these Roll Pin Holders in both standard and premium versions: Standard Roll Pin Holders: Constructed from durable steel, these holders provide reliable performance for general gunsmithing tasks. Premium Roll Pin Holders: Made from 5/16" hex high carbon 5160 steel that is Bainite heat treated for enhanced strength. Each holder features a single groove in the grip section and is laser marked for quick identification. Incorporating Brownells Roll Pin Holders into your gunsmithing toolkit enhances efficiency and precision, ensuring that roll pins are installed correctly without compromising the integrity of the firearm components.



Attributes

- Name: [BROWNEllS ROLL PIN HOLDER #1, 1/16" \(1.6MM\)](#)
- Manufacturer: [BROWNEllS](#)
- Product no.: 080685062
- Mfr. No.:
- Material: Steel
- Size: 1/16 in
- Style: Roll Pin
- Delivery weight: 0.025kg
- Shipping height: 8mm
- Shipping width: 89mm
- Shipping length: 147mm
- UPC: 050806017818

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for ROLL PIN HOLDERS BROWNELLS #1 1/16" (1.6MM) ROLL PIN HOLDER
- About Us

Safety Instruction Guide for ROLL PIN HOLDERS BROWNELLS #1 1/16" (1.6MM) ROLL PIN HOLDER

Introduction

Thank you for choosing the ROLL PIN HOLDERS BROWNELLS #1 1/16" (1.6MM) ROLL PIN HOLDER. This tool is designed to hold roll pins securely and align them perfectly for starting. It is especially useful for small, hard-to-grasp pins or those in tight spaces. This guide provides important safety instructions and usage information to ensure safe and effective operation.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always inspect the product for damage before use. Do not use if any part is damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Use appropriate personal protective equipment (PPE) such as safety goggles and gloves when using the tool.
- Be aware of your surroundings and ensure that the workspace is clear of hazards.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always secure the workpiece before using the roll pin holder to prevent slipping.
- Do not use excessive force when driving roll pins; this may damage the tool or the workpiece.
- Ensure that your hands are clear of the working area to avoid injury.
- Use the roll pin punch to finish driving the pin after it has been started with the holder.
- Do not modify the roll pin holder in any way, as this may compromise safety.

Instructions for Installation and Usage

1. Preparation

- Select the appropriate size roll pin holder for your application (1/16" for M16/AR15 rear sight or 3.5mm for Sig handguns).
- Ensure that the work area is clean and free from obstructions.

2. Using the Roll Pin Holder

- Insert the roll pin into the holder, ensuring it is properly seated.
- Align the roll pin holder with the hole where the pin will be inserted.
- Gently tap the holder with a hammer to start the roll pin. Ensure it is aligned straight to avoid bending.
- Once the pin is started, use a roll pin punch to drive it in completely.
- If resistance is met, stop and check alignment before proceeding.

3. Post-Use Care

- Clean the roll pin holder after use to remove any debris or contaminants.
- Store the roll pin holder in a safe, dry place, away from children.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste if it is damaged or broken.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For any safety inquiries or additional information, please refer to your local authorities or safety organizations. Always ensure you are following the latest safety guidelines and regulations.

By following these safety instructions, you can ensure a safe and effective experience with the ROLL PIN HOLDERS BROWNELLS #1 1/16" (1.6MM) ROLL PIN HOLDER. Thank you for prioritizing safety in your use of this product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk