

RUGER® ACTION WRENCH - COMPLETE ACTION WRENCH FOR RUGER® SINGLE ACTION

[Gunsmith Tools & Supplies](#) > [Handgun Tools](#) > [Action & Frame Tools](#) > [Action Wrenches](#)

Aluminum heads completely enclose those fragile, single action frames to help eliminate expensive frame damage.



Attributes

- Name: [COMPLETE ACTION WRENCH FOR RUGER® SINGLE ACTION](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080800174
- Mfr. No.:
- Make: Ruger
- Model: Universal Handguns
- Delivery weight: 3.334kg
- UPC: 050806020825

Item details

Made in USA

Table of Contents

- Startpage
- RUGER® ACTION WRENCH COMPLETE ACTION WRENCH FOR RUGER® SINGLE ACTION Safety Instruction Guide
- About Us

RUGER® ACTION WRENCH COMPLETE ACTION WRENCH FOR RUGER® SINGLE ACTION Safety Instruction Guide

Introduction

Thank you for purchasing the RUGER® Action Wrench Complete Action Wrench for Ruger® Single Action. This product is designed to assist you in safely and effectively working on your Ruger firearms. Please read this safety instruction guide carefully to ensure proper use and to minimize the risk of injury or damage.

General Safety Guidelines

- Always read and understand the product manual before use.
- Ensure that the wrench is suitable for the specific model of your firearm.
- Inspect the wrench for any damage or wear before each use.
- Keep this product out of reach of children and vulnerable individuals.
- Use the wrench in a welllit and stable environment.
- Always wear appropriate personal protective equipment, such as safety glasses and gloves, when using the wrench.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Before using the wrench, ensure that the firearm is unloaded and that the chamber is clear.
- Do not apply excessive force when using the wrench; this may damage the firearm or the wrench itself.
- Always use the correct interchangeable head for your specific firearm model.
- Do not modify the wrench or use it for purposes other than intended.
- Avoid using the wrench in wet or damp conditions to prevent slipping.
- Be cautious of sharp edges on the wrench and the firearm during use.

Instructions for Installation and Usage

1. Preparation:

- Make sure you have the correct interchangeable head for your Ruger firearm model.
- Gather all necessary tools and ensure you are in a safe working environment.

2. Attaching the Interchangeable Head:

- Align the interchangeable head with the base/handle unit.
- Secure the head by twisting it clockwise until it is firmly attached.

3. Using the Wrench:

- Position the wrench over the firearm's action, ensuring a snug fit.
- Apply gentle pressure while turning the wrench to avoid damaging the firearm.
- If resistance is met, stop and reassess the fit rather than applying excessive force.

4. After Use:

- Detach the interchangeable head from the base/handle unit by twisting it counterclockwise.

- Clean the wrench to remove any debris or residue.
- Store the wrench in a dry and safe location, away from children.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the wrench in household waste.
- If the product is damaged beyond repair, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product concerns, please refer to the contact information provided by your retailer or manufacturer. It is important to have a point of contact for any safetyrelated issues.

By following these safety instructions, you can ensure the safe and effective use of the RUGER® Action Wrench Complete Action Wrench for Ruger® Single Action. Always prioritize safety and proper handling to enjoy your firearm responsibly.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at