

1911 ALLEN HEAD GRIP SCREWS BLUED 24 PACK

[Handgun Parts](#) > [Grip Parts](#) > [Grip Screws](#)

No-Slip Head With A Custom Look

Puts an end to scratched and marred screw heads on 1911 Auto pistols. Machined and hardened screws use an Allen head socket to prevent the wrench from slipping and making your "masterpiece" look less-than-perfect.



Attributes

- Name: [1911 ALLEN HEAD GRIP SCREWS BLUED 24 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080831024
- Mfr. No.:
- Make: 1911
- Model: Officers, Commander, Government
- Quantity: 24
- Delivery weight: 0.045kg
- Shipping height: 18mm
- Shipping width: 86mm
- Shipping length: 122mm
- UPC: 050806014381

Item details

Made in USA

Table of Contents

- Startpage
- 1911 Allen Head Grip Screws Safety Instruction Guide
- About Us

1911 Allen Head Grip Screws Safety Instruction Guide

Introduction

Thank you for choosing the 1911 Allen Head Grip Screws. These screws are designed to enhance the appearance and functionality of your 1911 Auto pistols while ensuring a secure fit. This guide provides important safety instructions and information to help you use this product safely and effectively.

General Safety Guidelines

- Ensure safe handling and installation of the screws to avoid injury.
- Always inspect the screws for any damage before use.
- Keep the screws and tools out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use only the recommended Allen wrench to avoid slipping and damaging the screw head.
- Do not overtighten the screws as this may strip the threads or damage the grip.
- Avoid using the screws in environments that may expose them to extreme temperatures or corrosive substances.
- If you notice any unusual wear or damage to the screws, discontinue use immediately and replace them.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including the provided Allen wrench.
- Ensure that the work area is clean and welllit.

2. Installation Steps:

- Remove the existing grip screws from your 1911 Auto pistol using the appropriate tool.
- Align the new Allen Head Grip Screws with the holes in the grip panel.
- Insert the screws and handtighten them to ensure they are seated properly.
- Use the Allen wrench to tighten the screws further, ensuring they are snug but not overtightened.

3. PostInstallation Check:

- Verify that the grip is securely attached and that there is no movement.
- Ensure that the screws are flush with the grip surface to prevent snagging or injury.

Disposal Instructions

- Dispose of any damaged or unused screws in accordance with local regulations.
- Do not dispose of screws in a manner that could pose a risk to the environment or public safety.

Contact Information for Further Support

For any inquiries regarding safety or product issues, please refer to the product packaging or manufacturer's website for appropriate contact information.

Thank you for your attention to these safety instructions. Enjoy using your 1911 Allen Head Grip Screws responsibly and safely.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at