

1911 ALLEN HEAD GRIP SCREWS STAINLESS STEEL 4 PACK

[Handgun Parts](#) > [Grip Parts](#) > [Grip Screws](#)

No-Slip Head With A Custom Look

Puts an end to scratched and marred screw heads on 1911 Auto pistols. Machined and hardened screws use an Allen head socket to prevent the wrench from slipping and making your "masterpiece" look less-than-perfect.



Attributes

- Name: [1911 ALLEN HEAD GRIP SCREWS STAINLESS STEEL 4 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080831104
- Mfr. No.:
- Make: 1911
- Model: Commander, Government, Officers
- Quantity: 4
- Delivery weight: 0.009kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806014404

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Allen Head Grip Screws
- About Us

Safety Instruction Guide for 1911 Allen Head Grip Screws

Introduction

Thank you for choosing the 1911 Allen Head Grip Screws. This product is designed to enhance the appearance and functionality of your 1911 Auto pistol by preventing damage to screw heads. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the 1911 Allen Head Grip Screws by following all instructions outlined in this guide.
- **Enhanced Recalls:** Stay informed about product recalls. In the event of a recall, you will be provided with standardized notices and remedies.
- **Online Shopping:** If purchased online, ensure that the seller complies with safety requirements equivalent to those of physical stores.
- **Special Consumer Focus:** This product is not intended for use by children. Keep out of reach of minors.
- **EU Contact Point:** For any safety inquiries, please refer to the appropriate EU contact point.
- **Rapid Alerts:** Check the EU Safety Gate platform for updates on product safety and recalls.

Specific Safety Precautions for Use

- **Avoid Overtightening:** Overtightening the screws may lead to damage to the grip or the screws themselves.
- **Use Appropriate Tools:** Always use the provided Allen wrench to avoid slipping and damaging the screw heads.
- **Inspect Before Use:** Regularly inspect screws for signs of wear or damage. Do not use damaged screws.
- **Handle with Care:** When installing or removing screws, handle them carefully to prevent injury.

Instructions for Installation and Usage

1. Gather Tools:

- Allen wrench (included in the pack)
- Screwdriver (if necessary for grip removal)

2. Remove Existing Screws:

- Use a screwdriver to remove the existing grip screws if applicable.
- Place the removed screws in a safe location.

3. Install New Screws:

- Align the new Allen Head Grip Screws with the holes in the grip.
- Insert the screws and handtighten them initially.

4. Tighten Screws:

- Use the provided Allen wrench to tighten the screws securely.
- Do not overtighten; ensure screws are snug but not excessively tight.

5. Final Inspection:

- After installation, check the screws to ensure they are properly seated and secure.
- Inspect the grip for any misalignment or damage.

Disposal Instructions

- Dispose of any old screws and packaging materials in accordance with local regulations.
- Do not dispose of screws in regular household waste if they are damaged or potentially hazardous.

Contact Information for Further Support

For any questions or concerns regarding the 1911 Allen Head Grip Screws, please refer to the manufacturer's contact information provided with your purchase. Always ensure you have the product details available when seeking assistance.

By following these guidelines, you can ensure the safe and effective use of your 1911 Allen Head Grip Screws. Thank you for your attention to these important safety instructions.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at