

RUGER® MK I™/MK II™ ALLEN HEAD GRIP SCREWS - ALLEN HEAD GRIP SCREWS FOR RUGER MK I & MK II 4 PACK

[Handgun Parts](#) > [Grip Parts](#) > [Grip Screws](#)

Improved Looks & Function

These excellent looking Allen-head screws will dress up any Ruger® Mk I™ or Mk II™ pistol plus give positive wrench engagement to help prevent stripped-out grip screws. Same diameter head as the standard screw, fits flush on all factory and aftermarket grips.



Attributes

- Name: [ALLEN HEAD GRIP SCREWS FOR RUGER MK I & MK II 4 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 080832004
- Mfr. No.: 640200SCREW
- Make: Ruger
- Model: Mark I,Mark II
- Quantity: 4
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806014435

Item details

Made in USA

Table of Contents

- Startpage
- RUGER® MK I™ /MK II™ ALLEN HEAD GRIP SCREWS SAFETY INSTRUCTIONS
- About Us

RUGER® MK I™/MK II™ ALLEN HEAD GRIP SCREWS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the RUGER® MK I™/MK II™ Allen Head Grip Screws. This product is designed to enhance the appearance and functionality of your Ruger® Mk I™ or Mk II™ pistol. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Always inspect the product for any signs of damage before use.
- Follow the installation and usage instructions closely to avoid accidents.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use the correct size Allen wrench (3/32") to install or remove the grip screws.
- Do not overtighten the screws, as this may strip the threads or damage the grips.
- Ensure that the screws are installed flush with the grip surface to avoid snagging or injury.
- Store the screws in a safe, dry location when not in use to prevent rust and corrosion.
- If you notice any unusual wear or damage to the screws, discontinue use immediately.

Instructions for Installation and Usage

1. Preparation:

- Gather the necessary tools: a 3/32" Allen wrench and a soft cloth.
- Ensure your work area is clean and free of distractions.

2. Installation:

- Remove the existing grip screws from your Ruger® Mk I™ or Mk II™ pistol using the Allen wrench.
- Align the new Allen head grip screws with the grip holes.
- Handtighten the screws to ensure they are properly seated.
- Using the Allen wrench, tighten the screws gently until they are secure, but do not overtighten.

3. Usage:

- After installation, check the screws periodically to ensure they remain tight and secure.
- Avoid using excessive force when handling the pistol, as this can affect the screws.

Disposal Instructions

- Dispose of any damaged or worn screws in accordance with local regulations.
- Do not dispose of the product in regular household waste if it can be recycled.
- Check with local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or support regarding the RUGER® MK I™/MK II™ Allen Head Grip Screws, please refer to the manufacturer's website or contact your local retailer.

By following these safety instructions, you can ensure a safe and enjoyable experience with your RUGER® MK I™/MK II™ Allen Head Grip Screws. Thank you for your attention to safety.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at