

# 1911 SLIDE BUFFERS - SLIDE BUFFERS, 6 PACK

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Buffers](#)

## Prevent Slide-To-Frame Contact & Damage

Eliminates frame damage caused by slide/frame battering during the recoil cycle. A single, extra-defense, polyurethane buffer fits between the guide rod head and the recoil spring; completely prevents the slide from contacting the frame. Precisely molded so they won't drag on the frame and cause malfunctions. For best results, change every 1,000 rounds.



## Attributes

- Name: [SLIDE BUFFERS, 6 PACK](#)
- Manufacturer: [ED BROWN](#)
- Product no.: 087805006
- Mfr. No.: 805
- Make: 1911
- Model: Government
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 800732805009

## Item details

Made in USA

# Table of Contents

- Startpage
- 1911 Slide Buffers Safety Instruction Guide
- About Us

# 1911 Slide Buffers Safety Instruction Guide

## Introduction

Thank you for purchasing the 1911 Slide Buffers, a crucial accessory designed to enhance the performance and longevity of your firearm. This guide provides essential safety instructions and guidelines for the proper use and maintenance of your slide buffers. Adhering to these instructions will help ensure your safety and the safe operation of your firearm.

## General Safety Guidelines

- Always handle firearms with care and respect.
- Ensure that your firearm is unloaded before installing or inspecting the slide buffers.
- Keep the slide buffers out of reach of children and unauthorized users.
- Regularly check for wear and tear on the slide buffers; replace them every 1,000 rounds for optimal performance.
- Report any unsafe product incidents to the appropriate authorities.
- Stay informed about product recalls via the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Use the slide buffers only with 1911 Auto models.
- Ensure the buffers are properly installed to prevent frame damage and malfunctions.
- Do not attempt to modify the slide buffers in any way.
- Always wear appropriate eye and ear protection when handling firearms.
- Be aware of your surroundings and ensure a safe shooting environment.

## Instructions for Installation and Usage

### 1. Preparation

- Make sure your firearm is completely unloaded.
- Gather necessary tools for installation, if any.

### 2. Installation of Slide Buffers

- Remove the recoil spring and guide rod from your firearm.
- Place the polyurethane buffer between the guide rod head and the recoil spring.
- Ensure that the buffer is positioned correctly to avoid contact with the frame.
- Reassemble the recoil spring and guide rod into the firearm.

### 3. Usage

- After installation, perform a function check to ensure the firearm operates smoothly.
- Monitor the performance of the slide buffers during use and check for any signs of wear.
- Replace the slide buffers after every 1,000 rounds or sooner if damage is observed.

## Disposal Instructions

- Dispose of old or worn slide buffers in accordance with local regulations.
- Do not dispose of slide buffers in regular household waste; check for recycling options if available.

## **Contact Information for Further Support**

For any questions or concerns regarding the use of the 1911 Slide Buffers, please consult your retailer or manufacturer for assistance. It is essential to ensure that you have the correct information and support for your product.

By following these guidelines and instructions, you can maximize the safety and effectiveness of your 1911 Slide Buffers, ensuring a reliable and enjoyable shooting experience. Thank you for your attention to these important safety measures.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)