

1911 MAINSPRING CAP - MAINSPRING CAP FOR 1911, BLUED, 6 PACK

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainspring Caps](#)

U.S.-Made Parts For The 1911 Auto Pistol

Each and every part is U.S.-made, high-quality and guaranteed to fit and function just like the factory part.



Attributes

- Name: [MAINSPRING CAP FOR 1911, BLUED, 6 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 100000876
- Mfr. No.:
- Finish: Blued
- Make: 1911
- Model: Commander, Government
- Delivery weight: 0.136kg
- Shipping height: 18mm
- Shipping width: 86mm
- Shipping length: 142mm
- UPC: 050806029293

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Mainspring Cap
- About Us

Safety Instruction Guide for 1911 Mainspring Cap

Introduction

Thank you for choosing the 1911 Mainspring Cap, a highquality, U.S.made product designed for use with 1911 Auto firearms. This guide provides essential safety instructions to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always follow the manufacturer's instructions and guidelines.
- Regularly inspect the product for any signs of damage or wear.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear when handling firearms or firearm components.
- Do not use the mainspring cap if it shows any signs of damage or defects.
- Ensure that the firearm is unloaded before installing or replacing the mainspring cap.
- Avoid using the product in environments that may expose it to extreme temperatures or moisture.
- Store the product in a cool, dry place when not in use.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools for installation, including a screwdriver and any other required equipment.
- Ensure that your work area is clean and free from distractions.

2. Installation Steps

- Verify that the firearm is completely unloaded.
- Remove the old mainspring cap by following the manufacturer's guidelines for disassembly.
- Take the new 1911 Mainspring Cap from the packaging.
- Align the new mainspring cap with the designated area on the firearm.
- Securely fasten the mainspring cap in place according to the manufacturer's instructions.
- Doublecheck that the mainspring cap is firmly installed before proceeding.

3. Usage

- After installation, perform a function check of the firearm to ensure proper operation.
- Always handle the firearm with care and in a safe manner.

Disposal Instructions

- Dispose of any old or damaged mainspring caps in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Check with local authorities for proper disposal methods for firearm components.

Contact Information for Further Support

For any questions or concerns regarding the 1911 Mainspring Cap, please refer to the manufacturer's contact information provided in the product packaging or on their official website.

Thank you for prioritizing safety and compliance while using the 1911 Mainspring Cap. Enjoy your product responsibly!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at