

1911 MAINSPRING CAP PIN - BROWNELLS MAINSPRING CAP PIN FOR 1911, SS, 1 PACK

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainspring Cap Pins](#)

U.S.-Made Parts For The 1911 Auto Pistol

Each and every part is U.S.-made, high-quality and guaranteed to fit and function just like the factory part.



Attributes

- Name: [BROWNELLS MAINSPRING CAP PIN FOR 1911, SS, 1 PACK](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 100000880
- Mfr. No.: A21S
- Finish: Stainless Steel
- Model: Commander, Government, Officers
- Weapon type: 1911
- Delivery weight: 0.045kg
- Shipping width: 83mm
- Shipping length: 146mm
- UPC: 050806029323

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instructions for 1911 Mainspring Cap Pin
- About Us

Safety Instructions for 1911 Mainspring Cap Pin

Introduction

Thank you for choosing the 1911 Mainspring Cap Pin by Brownells. This product is designed to provide highquality performance and reliability. It is essential to read and follow these safety instructions to ensure safe usage and compliance with EU safety regulations.

General Safety Guidelines

- Ensure that all parts are installed correctly to avoid malfunctions.
- Do not modify or alter the product in any way.
- Store the product in a dry place away from direct sunlight and moisture.
- Inspect the product regularly for signs of wear or damage.
- Keep this product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents involving this product to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use only with compatible 1911 models: Government, Commander, and Officers.
- Ensure that you are wearing appropriate safety gear, such as eye protection, when handling firearms.
- Handle all firearm components with care to prevent accidental discharge.
- Follow all local laws and regulations regarding the use and storage of firearms.
- If you are inexperienced with firearm maintenance, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (e.g., punch tool, hammer).

2. Installation:

- Remove the existing mainspring cap pin from the firearm, if applicable.
- Align the new mainspring cap pin with the corresponding hole in the mainspring housing.
- Gently tap the pin into place using a punch tool and hammer, ensuring it is securely fitted.

3. PostInstallation Check:

- Inspect the installation to ensure that the pin is flush and properly seated.
- Test the functionality of the mainspring to ensure smooth operation.

4. Usage:

- Regularly check the pin for signs of wear or damage during routine firearm maintenance.
- Replace the pin if it shows signs of significant wear to maintain safety and performance.

Disposal Instructions

- Dispose of any damaged or worn parts in accordance with local regulations.
- Do not dispose of in regular household waste; check for local hazardous waste disposal options if necessary.

Contact Information for Further Support

For any inquiries regarding safety or functionality, please consult with a qualified gunsmith or contact the manufacturer directly.

By following these guidelines, you can ensure safe and effective use of the 1911 Mainspring Cap Pin. Thank you for prioritizing safety and compliance with EU General Product Safety Regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk