

# 1911 ADJUSTABLE REAR NIGHT SIGHTS - REAR SIGHTS, TR FITS S&W

[Handgun Parts](#) > [Sights](#) > [Rear Sights](#)

CNC-machined, steel, rear sight with Novak's famous, low-profile design and the added versatility of elevation and windage adjustments. Set screw allows drift adjustment for windage; elevation screw positively stops and audibly clicks for easy fine-tuning. Smooth, contoured edges have less chance of catching or snagging. Front sights are CNC-machined steel and mount in factory dovetail. Available in Tritium Dot for Colt and clones and SW1911 pistols.



## Attributes

- Name: [REAR SIGHTS, TR FITS S&W](#)
- Manufacturer: [NOVAK](#)
- Product no.: 100001526
- Mfr. No.: ASW191103
- Make: 1911
- Model: Officers, Commander, Government
- Sight Color: Green
- Style: 2-Dot, Adjustable, Low-Profile
- Delivery weight: 0.005kg
- Shipping height: 1mm
- Shipping width: 83mm
- Shipping length: 146mm

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Adjustable Rear Night Sights
- About Us

# Safety Instruction Guide for 1911 Adjustable Rear Night Sights

## Introduction

Thank you for choosing the 1911 Adjustable Rear Night Sights. This guide provides important safety information and instructions to ensure the safe and effective use of your product. Please read this guide carefully before installation and usage.

## General Safety Guidelines

- Ensure that the product is installed by a qualified gunsmith or individual with experience in firearm modifications.
- Always handle firearms with care and follow standard safety practices.
- Keep the product away from children and unauthorized users.
- Regularly check the sights for any signs of wear or damage.
- If you notice any issues, discontinue use immediately and consult a professional.

## Specific Safety Precautions for Use

- Always ensure your firearm is unloaded before installing or adjusting the sights.
- Avoid using excessive force when making adjustments to prevent damage.
- Do not attempt to modify the sights beyond the intended adjustments for windage and elevation.
- Ensure that the sight is securely mounted before use to prevent it from becoming loose during operation.

## Instructions for Installation and Usage

### 1. Installation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the existing rear sight by loosening the set screw.
- Align the new adjustable rear sight in the factory dovetail.
- Secure the sight in place by tightening the set screw.
- Check for proper alignment and adjust if necessary.

### 2. Adjustments

- Windage Adjustment:
  - Use the set screw to drift the sight left or right as needed.
- Elevation Adjustment:
  - Turn the elevation screw to raise or lower the sight. The screw will click audibly to indicate adjustments.

### 3. Usage

- Regularly check the sight alignment before each use.
- Familiarize yourself with the sighting system to improve accuracy.
- Practice shooting in a controlled environment to ensure comfort with the new sights.

## Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.

- Contact your local waste management authority for guidance on proper disposal methods.

## Contact Information for Further Support

For any inquiries or additional support regarding the 1911 Adjustable Rear Night Sights, please contact your local distributor or retailer.

Thank you for prioritizing safety and compliance with the guidelines provided in this instruction guide. Enjoy your enhanced shooting experience with your new sights!

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)