

# 1911 AUTO MAXBEVEL MAINSPRING HOUSING - STAN CHEN CUSTOMS MAXBEVEL MSH, SS

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainspring Housings](#)

Larger Magazine Well Bevel for Faster Reloads with No Extra Bulk Unique design allows the custom gunsmith to seamlessly cut the bevel of the magwell back into the mainspring housing, allowing a much larger magwell opening without an add on magwell. Proprietary BevelBlock™ fitting block of extra material on the front ledge of the mainspring housing forms a seamless butt joint with the frame, deep into the frame's magazine well. The BevelBlock now comes pre-machined with an angled rear bevel to make installation even simpler, while still allowing the gunsmith to shape to their own profile, if desired. Allows shooters to hit the sweet spot at the rear of the magwell during combat reloads. Machined to maximum dimensions to deliver a nice snug fit in most 1911 frames without excessive material removal. Perfect for carry applications to greatly increase the magwell opening with no extra bulk. Requires one simple machine cut for installation before final shaping. Available in flat and smooth, or custom quality checkered at 20, 25 or 30 lines per inch by master metalsmith Pete Single. Perfectly formed diamonds improve grip and control during rapid fire. Rounded heel increases shooting and carry comfort. Precision machined from tough, solid barstock for extreme durability.



## Attributes

- Name: [STAN CHEN CUSTOMS MAXBEVEL MSH, SS](#)
- Manufacturer: [STAN CHEN CUSTOMS](#)
- Product no.: 100005027
- Mfr. No.: CMSH-SS
- Finish: Stainless Steel
- Model: Commander, Government
- Weapon type: 1911
- Delivery weight: 0.091kg
- Shipping height: 38mm
- Shipping width: 147mm
- Shipping length: 229mm

## Item details

Made in USA

US export classification: 0A501.y.1

# Table of Contents

- Startpage
- Safety Instruction Guide for 1911 AUTO MAXBEVEL MAINSPRING HOUSING
- About Us

# Safety Instruction Guide for 1911 AUTO MAXBEVEL MAINSPRING HOUSING

## Introduction

Thank you for purchasing the 1911 AUTO MAXBEVEL MAINSPRING HOUSING by Stan Chen Customs. This product has been designed to enhance the performance of your 1911 pistol while ensuring safety during use. Please read this safety instruction guide carefully to ensure proper installation and safe use of the product.

## General Safety Guidelines

- Always handle firearms with care and follow the basic rules of firearm safety.
- Ensure that the product is compatible with your specific 1911 model (Government or Commander).
- Inspect the mainspring housing and your firearm for any signs of damage or wear before installation.
- Keep this product out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Do not attempt to install the mainspring housing if you are not a qualified gunsmith.
- Ensure that the firearm is unloaded before beginning installation.
- Use appropriate personal protective equipment (PPE) such as safety glasses and gloves during installation.
- Be cautious of sharp edges and debris during the installation process.
- Avoid excessive force during installation to prevent damage to the firearm or the product.
- If you experience any difficulty during installation, seek assistance from a professional gunsmith.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure your workspace is clean and welllit.
- Gather necessary tools, including a fitting block and machining tools.

### 2. Installation Steps:

- Verify that the firearm is unloaded and safe to work on.
- Remove the existing mainspring housing from your 1911 pistol.
- Using the proprietary BevelBlock™ fitting block, align the MAXBEVEL Mainspring Housing with the frame.
- Make one simple machine cut as required for installation, ensuring not to remove excessive material.
- Shape the rear bevel to your desired profile if necessary.
- Carefully install the MAXBEVEL Mainspring Housing, ensuring a snug fit.
- Check for proper alignment and function before reassembling your firearm.

### 3. PostInstallation:

- Conduct a thorough inspection of the firearm to ensure all components are securely in place.
- Test the functionality of the magwell and mainspring housing by performing dry fire exercises.
- If any issues arise, consult a professional gunsmith before using the firearm.

## **Disposal Instructions**

- Dispose of any packaging materials in accordance with local regulations.
- If the product is no longer usable, follow local guidelines for the disposal of metal components.

## **Contact Information for Further Support**

For any questions or support regarding the 1911 AUTO MAXBEVEL MAINSPRING HOUSING, please refer to the contact information provided with your product packaging or visit the manufacturer's website.

By following these safety instructions, you can ensure the safe and effective use of your 1911 AUTO MAXBEVEL MAINSPRING HOUSING. Thank you for your attention to safety and responsible firearm handling.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)