

GUIDE ROD REDUCING RING for GLOCK® GEN4 - ZEV TECHNOLOGIES GEN4 REDUCING RING

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

Lets You Use Gen3 Guide Rods & Springs In Your Gen4

Stainless steel ring fits into the end of a Gen4 slide to enable use of narrower-diameter Gen3 guide rods and springs. Increases your choice of aftermarket guide rod/recoil spring combinations for tuning the performance of your Gen4 pistol. Compatible with both captured and uncaptured springs.



Attributes

- Name: [ZEV TECHNOLOGIES GEN4 REDUCING RING](#)
- Manufacturer: [ZEV TECHNOLOGIES](#)
- Product no.: 100006593
- Mfr. No.:
- Make: Glock
- Model: Universal Handguns
- Delivery weight: 0.007kg
- UPC: 811745022215

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [GUIDE ROD REDUCING RING Safety Instructions](#)
- [About Us](#)

GUIDE ROD REDUCING RING Safety Instructions

Introduction

Thank you for choosing the GUIDE ROD REDUCING RING for GLOCK® GEN4 by ZEV TECHNOLOGIES. This product is designed to enhance the performance of your Gen4 pistol by allowing the use of narrower diameter Gen3 guide rods and springs. Please read this safety instruction guide thoroughly to ensure safe and effective use of the product.

General Safety Guidelines

- Always handle firearms and related accessories with care and follow all safety precautions.
- Ensure that the GUIDE ROD REDUCING RING is compatible with your specific firearm model.
- Regularly check for any signs of wear or damage to the GUIDE ROD REDUCING RING before use.
- Store the GUIDE ROD REDUCING RING in a safe place, away from children and unauthorized users.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use the GUIDE ROD REDUCING RING with Glock Gen4 pistols.
- Ensure that the installation is performed by a qualified individual or gunsmith if you are not confident in your ability to do it safely.
- Do not modify the GUIDE ROD REDUCING RING or any components of your firearm.
- Avoid using the GUIDE ROD REDUCING RING with captured springs if you are unfamiliar with their operation.
- Always wear appropriate safety gear, such as eye protection, when handling firearms.

Instructions for Installation and Usage

1. Preparation:

- Ensure your firearm is unloaded and in a safe condition before beginning the installation.
- Gather necessary tools, including a punch tool and a hammer if required.

2. Installation:

- Remove the slide from your Glock Gen4 pistol.
- Locate the end of the slide where the GUIDE ROD REDUCING RING will be installed.
- Carefully insert the GUIDE ROD REDUCING RING into the end of the slide, ensuring a snug fit.
- If necessary, use a punch tool to gently tap the ring into place, ensuring it is fully seated.

3. Reassembly:

- Reinstall the slide onto your Glock Gen4 pistol.
- Ensure that the guide rod and recoil spring are properly aligned and seated.

4. Usage:

- Test the operation of the firearm in a safe environment before regular use.
- Monitor the performance of your firearm, and check the GUIDE ROD REDUCING RING for any signs of wear or damage after each use.

Disposal Instructions

- Dispose of the GUIDE ROD REDUCING RING in accordance with local regulations regarding metal waste.
- Do not dispose of the product in regular household waste. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the GUIDE ROD REDUCING RING, please refer to the manufacturer's contact information provided with the product packaging or visit the manufacturer's website for more details.

Thank you for following these safety instructions. Your safety and the safety of others is our priority. Enjoy enhanced performance with your Glock Gen4 pistol!

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu