

STAINLESS STEEL GUIDE RODS - GLOCKPARTS.COM GR-1923 SS GUIDE ROD FITS G19/23/32/38

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

Can be used w/ factory or flat wound springs Rigid steel body improves lockup w/o "rod flex" Hex screw allows user to choose spring weights Will not chip or crack like plastic guiderods Blue loctite recommended on hex screw threads
Can be used w/ gen 4 glocks w/ conversion insert GR-1722 fits G17/17L/22/24/31/34/35/37 pistols GR-1923 fits G19/23/32/38 pistols



Attributes

- Name: [GLOCKPARTS.COM GR-1923 SS GUIDE ROD FITS G19/23/32/38](#)
- Manufacturer: [GLOCKPARTS.COM](#)
- Product no.: 100006813
- Mfr. No.: GR-1923
- Model: 19,23,32,38
- Weapon type: Glock
- Delivery weight: 0.018kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for STAINLESS STEEL GUIDE RODS GLOCKPARTS.COM GR1923
- About Us

Safety Instruction Guide for STAINLESS STEEL GUIDE RODS GLOCKPARTS.COM GR1923

Introduction

Thank you for choosing the STAINLESS STEEL GUIDE RODS GLOCKPARTS.COM GR1923. This product is designed to enhance the performance of your Glock pistols (models G19, G23, G32, and G38) by improving lockup and reducing "rod flex." It is essential to follow the safety guidelines outlined in this document to ensure safe and effective use of the product.

General Safety Guidelines

- Always ensure that your firearm is unloaded before installing or handling the guide rod.
- Keep the guide rod and all firearm components out of reach of children and unauthorized users.
- Regularly inspect the guide rod for signs of wear or damage.
- Use only compatible springs as specified in the product description.
- Always follow local laws and regulations regarding firearm accessories and modifications.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure the hex screw is securely tightened using blue Loctite to prevent loosening during use.
- Do not use the guide rod with any springs that exceed the manufacturer's specifications.
- Be cautious when handling the guide rod, as improper handling can lead to injury or damage.
- If you experience any malfunctions while using the guide rod, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation

- Ensure your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools, including a hex wrench for the hex screw.

2. Installation

- Remove the existing guide rod from your Glock pistol.
- Align the STAINLESS STEEL GUIDE ROD GR1923 with the recoil spring.
- Insert the guide rod into the recoil spring assembly.
- Use the hex wrench to secure the hex screw, ensuring it is tightened with blue Loctite for stability.

3. Usage

- After installation, perform a function check to ensure everything operates smoothly.
- Follow standard safety practices when handling your firearm.

4. Maintenance

- Regularly inspect the guide rod for wear and replace if necessary.
- Clean the guide rod with a suitable firearm cleaning solution to prevent corrosion.

Disposal Instructions

- Dispose of the guide rod in accordance with local regulations regarding metal recycling.
- Do not dispose of the guide rod in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the STAINLESS STEEL GUIDE RODS GLOCKPARTS.COM GR1923, please refer to the manufacturer's website or contact their customer support for assistance.

Thank you for your attention to these safety instructions. Your safety and the safe operation of your firearm are of utmost importance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk