

UNIVERSAL SHELL HOLDERS - LEE PRECISION LEE UNIVERSAL SHELLHOLDER, #16

[Reloading](#) > [Shellholders & Shellplates](#)

Universal shell holder used in most brands of reloading presses. Will not work with Lee Auto Prime. View Lee Shellholder Chart



Attributes

- Name: [LEE PRECISION LEE UNIVERSAL SHELLHOLDER, #16](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100010075
- Mfr. No.: 90003
- Cartridge: 500 S&W, 7.62 x 54 mm Russian, 8 x 56 mm Rimmed Hungarian
- Style: Press Type
- Delivery weight: 0.023kg
- Shipping height: 5mm
- Shipping width: 94mm
- Shipping length: 127mm
- UPC: 734307900038

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for UNIVERSAL SHELL HOLDERS LEE PRECISION LEE UNIVERSAL SHELLHOLDER, #16
- About Us

Safety Instruction Guide for UNIVERSAL SHELL HOLDERS LEE PRECISION LEE UNIVERSAL SHELLHOLDER, #16

Introduction

Thank you for choosing the LEE PRECISION UNIVERSAL SHELLHOLDER, #16. This product is designed to provide reliable performance for reloading ammunition. To ensure safe and effective use, please read and follow the safety guidelines and instructions outlined in this guide.

General Safety Guidelines

- Always ensure that you are using the correct shell holder for your specific reloading press and cartridge.
- Keep the shell holder out of reach of children and vulnerable individuals.
- Inspect the shell holder for any signs of damage before use. Do not use a damaged shell holder.
- Follow all manufacturer instructions for your reloading press and related equipment.
- Store the shell holder in a safe location when not in use.

Specific Safety Precautions for Use

- The UNIVERSAL SHELLHOLDER, #16 is not compatible with the Lee Auto Prime. Do not attempt to use it with this device.
- Ensure that the reloading press is securely mounted and stable before use.
- Always wear appropriate eye protection when reloading ammunition.
- Avoid wearing loose clothing or jewelry that could become caught in the reloading press.
- Do not exceed the recommended load limits for your cartridges.

Instructions for Installation and Usage

1. Installation

- Ensure that your reloading press is turned off and disconnected from any power source.
- Locate the shell holder slot on your reloading press.
- Insert the UNIVERSAL SHELLHOLDER, #16 into the shell holder slot, ensuring it is securely seated.
- Confirm that the shell holder is properly aligned with the press mechanism.

2. Usage

- Place the appropriate cartridge into the shell holder.
- Follow your reloading press instructions to complete the reloading process.
- After use, remove the shell holder from the press and clean it as necessary.

Disposal Instructions

- Dispose of the shell holder in accordance with local regulations.
- Do not dispose of the shell holder in regular household waste if it is damaged. Check with local waste management for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the use of the LEE PRECISION UNIVERSAL SHELLHOLDER, #16, please

refer to the manufacturer's website or contact their customer service for assistance.

By following these safety guidelines and instructions, you can ensure a safe and effective reloading experience. Thank you for prioritizing safety while using the LEE PRECISION UNIVERSAL SHELLHOLDER, #16.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk