

LEE CLASSIC LOADERS - LEE PRECISION 45 ACP LOADER

[Reloading](#) > [Reloading Dies](#) > [Handgun Dies](#)

Lee Loader is a complete reloading system, kit includes everything needed to reload Kit includes Sizing Die, Decapping Chamber, Bullet Seater and Priming Chamber, Priming Rod, Powder Measure, load data, plastic case and complete instructions Requires hammer or rubber mallet, not included "



Attributes

- Name: [LEE PRECISION 45 ACP LOADER](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100010079
- Mfr. No.: 90262
- Cartridge: 45 Auto (ACP)
- Die Style: -
- Delivery weight: 0.476kg
- Shipping height: 30mm
- Shipping width: 97mm
- Shipping length: 150mm
- UPC: 734307902629

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [LEE CLASSIC LOADERS LEE PRECISION 45 ACP LOADER Safety Instruction Guide](#)
- [About Us](#)

LEE CLASSIC LOADERS LEE PRECISION 45 ACP LOADER Safety Instruction Guide

Introduction

Thank you for choosing the LEE CLASSIC LOADERS LEE PRECISION 45 ACP LOADER. This guide provides essential safety instructions to ensure your safe and effective use of this reloading system. Please read and follow these instructions carefully to prevent accidents and injuries.

General Safety Guidelines

- Ensure that the reloading area is wellventilated and free from distractions.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves while reloading.
- Keep all components of the reloading system out of reach of children and unauthorized persons.
- Store all reloading materials, including powders and primers, in a secure location.
- Familiarize yourself with the operation and components of the loader before use.
- Follow all local, state, and national laws regarding ammunition reloading and storage.

Specific Safety Precautions for Use

- Use only the recommended components and materials specified in the loading data provided with the kit.
- Do not exceed the maximum load weights or use incompatible components.
- Inspect all equipment for damage or wear before use. Replace any damaged parts immediately.
- Ensure that your work surface is stable and that the loader is securely positioned during operation.
- Never attempt to reload ammunition while under the influence of drugs or alcohol.
- Always doublecheck your measurements and load data before proceeding with reloading.
- Keep your hands and other body parts clear of moving parts during operation.

Instructions for Installation and Usage

1. Setup:

- Place the loader on a stable, flat surface.
- Ensure that all components are accounted for: Sizing Die, Decapping Chamber, Bullet Seater, Priming Chamber, Priming Rod, Powder Measure, and load data.

2. Reloading Process:

◦ Sizing and Decapping:

- Insert the cartridge case into the Sizing Die and use the Priming Rod to decap the spent primer.

◦ Priming:

- Follow the instructions to insert a new primer into the Priming Chamber.

◦ Powder Measurement:

- Use the Powder Measure to accurately dispense the recommended amount of powder for your load.

- **Bullet Seating:**

- Place a bullet on top of the charged case and use the Bullet Seater to ensure proper seating depth.

3. Completion:

- Inspect each completed round for consistency and safety.
- Store completed ammunition in a secure and labeled container.

Disposal Instructions

- Dispose of any unused or expired reloading materials in accordance with local regulations.
- Do not dispose of hazardous materials in regular trash. Contact local waste management services for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further support, please refer to the contact details provided with your product packaging or visit the manufacturer's website.

Please ensure that you keep this guide for future reference and share it with anyone who may use the LEE CLASSIC LOADERS LEE PRECISION 45 ACP LOADER. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk