

RIFLE CREEDMOOR REAR SIGHT - DAVIDE PEDERSOLI S.R.L RIFLE GOODWIN TANG SIGHT CREEDMOOR REAR SIGHT BLACK

[Rifle Parts](#) > [Sights](#) > [Rear Sights](#)

Named after the famous range on Long Island that hosted many long-range rifle competitions in the 1870s and '80s, the Creedmoor ladder-type sight is fully adjustable for windage and elevation and works equally well on cartridge rifles and muzzleloaders. Sight is precision machined from steel and attaches to tang with supplied setscrews and folds down when not in use. The Universal model is available in middle-range 2" and long-range 3" heights. The windage adjustment mechanism is on the eyepiece, allowing the eyepiece to be dropped close to the base for close-in shots. The Soule model provides maximum adjustability to fit any hunting or target shooting conditions. Elevation is adjustable in precise increments of 1 MOA, and one full turn of the windage knob moves the point of aim left or right by 2½ MOA in ½ minute increments. Large knurled knob at the sight base allows fast, accurate return to center or previous setting. Choice of Short, Middle, and Long Range models. The "Goodwin" style sight was a popular sight for long range shooters in the late 1800s. The "flag" position allows for a very wide windage adjustment range of 1.26". The elevation adjustment on the Goodwin has a range of 3.94". With the Goodwin's structure, the chamber can be easily accessed for cleaning or inspection. The Goodwin also has a "tilt" screw that allows the staff to be perfectly vertical at all elevations.



Attributes

- Name: [DAVIDE PEDERSOLI S.R.L RIFLE GOODWIN TANG SIGHT CREEDMOOR REAR SIGHT BLACK](#)
- Manufacturer: [DAVIDE PEDERSOLI S.R.L](#)
- Product no.: 100010691
- Mfr. No.: USA 407
- Colour: Black
- Model: Universal Rifles
- Style: Goodwin,Tang Sights
- Weapon type: Universal Rifles
- Delivery weight: 0.318kg
- Shipping height: 43mm
- Shipping width: 117mm
- Shipping length: 213mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for RIFLE CREEDMOOR REAR SIGHT](#)
- [About Us](#)

Safety Instruction Guide for RIFLE CREEDMOOR REAR SIGHT

Introduction

Thank you for purchasing the RIFLE CREEDMOOR REAR SIGHT by Davide Pedersoli S.R.L. This guide provides essential safety instructions to ensure your safe use of this product. Please read this guide carefully before installation and use.

General Safety Guidelines

- **Product Safety:** Always ensure the safe use of the rear sight and your rifle. Follow all safety instructions to minimize risks.
- **Enhanced Recalls:** Be aware of standardized recall notices. If you receive a recall notice, follow the provided instructions to return the product for a remedy.
- **Online Shopping:** If purchased online, ensure the platform complies with safety requirements similar to physical stores.
- **Special Consumer Focus:** Extra care should be taken when using this product around vulnerable groups, such as children.
- **EU Contact Point:** For safety inquiries, refer to your local EU contact point.
- **Rapid Alerts:** Stay informed about unsafe products through the EU's Safety Gate system.

Specific Safety Precautions for Use

- Always ensure the rifle is unloaded before installing or adjusting the rear sight.
- Use the rear sight only on compatible rifles as specified in the product specifications.
- Ensure that all screws and attachments are securely fastened before use.
- Avoid using the rear sight in adverse weather conditions that could affect visibility and safety.
- Regularly inspect the rear sight for any signs of wear or damage. Do not use if damaged.
- Keep the rear sight and rifle out of reach of children when not in use.
- Always wear appropriate eye protection when using firearms.

Instructions for Installation and Usage

1. Installation

- Ensure you have the necessary tools for installation, including a screwdriver for the setscrews.
- Locate the tang of your rifle where the rear sight will be attached.
- Align the rear sight with the mounting holes on the tang.
- Use the supplied setscrews to secure the sight to the tang. Ensure it is tightly fastened.
- Check the distance between mounting holes (2.20"2.29" or 5.65.8 cm) to ensure proper fit.
- If necessary, drill and tap the tang for proper installation.
- Fold the sight down when not in use to prevent damage.

2. Usage

- Adjust the elevation and windage settings before shooting to ensure accurate aim.
- The windage adjustment mechanism is located on the eyepiece. Adjust as needed for your shooting conditions.
- Elevation can be adjusted in increments of 1 MOA. Make small adjustments for precision.
- For closein shots, drop the eyepiece close to the base.
- Utilize the large knurled knob at the sight base for quick adjustments.
- After each shooting session, check the sight for any loosening or misalignment.

Disposal Instructions

- Dispose of the rear sight in accordance with local regulations for metal products.
- If the product is damaged beyond repair, ensure it is disposed of responsibly to minimize environmental impact.

Contact Information for Further Support

For further assistance regarding the RIFLE CREEDMOOR REAR SIGHT, please refer to the product packaging or your point of purchase for contact details.

By following these safety instructions, you will ensure the safe and effective use of your RIFLE CREEDMOOR REAR SIGHT. Thank you for your attention to safety and compliance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk