

AR-15 STANDARD FIRING PIN - RUBBER CITY ARMORY ENHANCED FIRING PIN

[Rifle Parts](#) > [Bolt Parts](#) > [Firing Pin Parts](#) > [Firing Pins](#)

Features: Stainless steel construction Black Nitride processing Engineered to last a lifetime Fits any standard AR15 or M16



Attributes

- Name: [RUBBER CITY ARMORY ENHANCED FIRING PIN](#)
- Manufacturer: [RUBBER CITY ARMORY](#)
- Product no.: 100012435
- Mfr. No.: BNSSFP15
- Weapon type: AR-15
- Delivery weight: 0.023kg
- Shipping height: 8mm
- Shipping width: 74mm
- Shipping length: 108mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Standard Firing Pin
- About Us

Safety Instruction Guide for AR15 Standard Firing Pin

Introduction

Thank you for choosing the AR15 Standard Firing Pin by Rubber City Armory. This guide provides important safety instructions and usage guidelines to ensure your product is used safely and effectively. Please read this document carefully before using the firing pin.

General Safety Guidelines

- Ensure that the firing pin is compatible with your AR15 or M16 bolt carrier group.
- Always handle firearms and their components with care and respect.
- Keep the firing pin and all firearm components out of reach of children and unauthorized users.
- Regularly inspect the firing pin for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use of firearms and their components.

Specific Safety Precautions for Use

- Do not use the firing pin if it shows any signs of damage or excessive wear.
- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Ensure that the firearm is unloaded when installing or removing the firing pin.
- Use only manufacturerapproved parts with your firearm to avoid compatibility issues.
- Be aware of your surroundings and ensure a safe environment when using firearms.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is completely unloaded and the bolt carrier group is removed from the firearm.
- Insert the AR15 Standard Firing Pin into the bolt carrier group, aligning it with the firing pin channel.
- Ensure that the firing pin is seated correctly and moves freely within the channel.
- Reassemble the bolt carrier group and ensure all components are secured properly.

2. Usage

- Always verify that the firearm is in a safe condition before loading ammunition.
- Follow the manufacturer's instructions for loading and firing your specific firearm.
- After firing, inspect the firing pin for any signs of damage or abnormal wear.
- Clean the firing pin and bolt carrier group regularly to maintain optimal performance.

Disposal Instructions

- Dispose of any damaged or worn firing pins in accordance with local regulations regarding hazardous materials.
- Do not dispose of the firing pin in regular household waste. Instead, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the AR15 Standard Firing Pin, please refer to the manufacturer's

contact information provided with your product packaging.

Conclusion

By following these safety instructions and guidelines, you can ensure the safe and effective use of the AR15 Standard Firing Pin. Always prioritize safety and responsibility when handling firearms and their components. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk