

AK CHEEK RISER FOR AK-47/74 - MAGPUL AK CHEEK RISER 1/4" POLYMER FOR AK-47/74 PLUM

[Rifle Parts](#) > [Stock Parts](#) > [Stock Hardware](#) > [Cheek Pieces](#)

Tool-less clip-on cheek risers for the MOE AK and Zhukov-S Stocks. Gives the user the option to raise the cheek weld .25 inches in height. Will not interfere with storage access on MOE Stock or the folding mechanism on the Zhukov-S Stock.



Attributes

- Name: [MAGPUL AK CHEEK RISER 1/4" POLYMER FOR AK-47/74 PLUM](#)
- Manufacturer: [MAGPUL](#)
- Product no.: 100016654
- Mfr. No.: MAG445-PLM
- Finish: Plum
- Material: Polymer
- Weapon type: AK-47,AK-74
- Delivery weight: 0.054kg
- Shipping height: 32mm
- Shipping width: 127mm
- Shipping length: 229mm
- UPC: 840815100614

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- Startpage
- AK Cheek Riser Safety Instructions
- About Us

AK Cheek Riser Safety Instructions

Introduction

Thank you for choosing the AK Cheek Riser for your AK47/74. This product is designed to enhance your shooting experience by providing a comfortable cheek weld. Please read this safety instruction guide carefully to ensure safe use and installation of your cheek riser.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always follow the manufacturer's instructions for installation and usage.
- Regularly inspect the cheek riser for any signs of wear or damage.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Do not exceed the recommended height adjustment of 0.25 inches.
- Ensure that the cheek riser is securely attached before use to prevent accidents.
- Avoid using the cheek riser if it shows any signs of damage or wear.
- Be aware of your surroundings and ensure that the cheek riser does not obstruct access to storage compartments or folding mechanisms.
- Use caution when adjusting the cheek riser to avoid pinching or injury.

Instructions for Installation and Usage

1. Installation:

- Remove the cheek riser from its packaging.
- Align the cheek riser with the designated mounting area on the MOE AK or ZhukovS Stock.
- Press down firmly to clip the riser onto the stock until you hear a click, indicating it is securely attached.
- Ensure that the riser does not obstruct any storage access or folding mechanisms.

2. Usage:

- When using the cheek riser, ensure that it is properly adjusted to your preferred height.
- Maintain a proper shooting stance and ensure that your cheek is resting comfortably on the riser.
- Regularly check the stability of the riser during use, especially after extended shooting sessions.

Disposal Instructions

- Dispose of the AK Cheek Riser in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, seek out recycling options for plastic materials.
- Ensure that the product is decommissioned and cannot be reused if it is damaged beyond repair.

Contact Information for Further Support

For any questions or concerns regarding the AK Cheek Riser, please refer to the manufacturer's website or customer support resources. Ensure you have your product details ready for any inquiries.

By following these safety instructions, you can ensure a safe and enjoyable experience with your AK Cheek Riser. Thank you for your attention to safety, and happy shooting!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk