

AK-47 3/4" CHEEK RISER - MAGPUL AK CHEEK RISER 3/4" POLYMER FOR AK-47/74 BLACK

[Rifle Parts](#) > [Stock Parts](#) > [Stock Hardware](#) > [Cheek Pieces](#)

Tool-less clip-on cheek risers for the MOE AK and Zhukov-S Stocks. Gives the user the option to raise the cheek weld .75 inches in height. Will not interfere with storage access on MOE Stock or the folding mechanism on the Zhukov-S Stock.



Attributes

- Name: [MAGPUL AK CHEEK RISER 3/4" POLYMER FOR AK-47/74 BLACK](#)
- Manufacturer: [MAGPUL](#)
- Product no.: 100016660
- Mfr. No.: MAG447-BLK
- Finish: Black
- Material: Polymer
- Weapon type: AK-47,AK-74
- Delivery weight: 0.073kg
- Shipping height: 32mm
- Shipping width: 127mm
- Shipping length: 229mm
- UPC: 840815100676

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- Startpage
- Safety Instruction Guide for AK47 3/4" Cheek Riser
- About Us

Safety Instruction Guide for AK47 3/4" Cheek Riser

Introduction

Thank you for choosing the AK47 3/4" Cheek Riser by MAGPUL. This product is designed to enhance your shooting experience by providing an adjustable cheek weld for improved accuracy and comfort. Please read this safety instruction guide carefully to ensure safe installation and use of this product.

General Safety Guidelines

- Always handle firearms and accessories with care and respect.
- Ensure that all products are used in accordance with the manufacturer's instructions.
- Regularly inspect the cheek riser for any signs of wear or damage before each use.
- Keep the product out of reach of children and unauthorized users.
- In case of any accidents or unsafe conditions, report them to the appropriate authorities.
- Stay informed about recalls and safety updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the cheek riser is securely attached before use to prevent it from coming loose during operation.
- Do not exceed the recommended height adjustment of 0.75 inches to maintain stability and safety.
- Avoid using the cheek riser with firearms that are not compatible, such as models other than AK47 or AK74.
- Be cautious when adjusting the cheek riser to avoid pinching fingers or causing injury.
- Use the product only in a safe and controlled environment, away from obstacles and bystanders.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Locate the mounting area on the MOE AK or ZhukovS Stock.
- Align the cheek riser with the designated clapon points.
- Press firmly until the cheek riser clicks into place, ensuring it is secure.

2. Usage:

- Adjust the cheek riser height by gently pulling up or pushing down as needed.
- Ensure that the cheek riser does not interfere with the firearm's mechanisms or storage access.
- Maintain a proper cheek weld to improve shooting accuracy and comfort.

3. PostUse Care:

- After use, inspect the cheek riser for any signs of damage or wear.
- Clean the cheek riser with a soft, dry cloth to remove any debris or moisture.
- Store the product in a cool, dry place away from direct sunlight.

Disposal Instructions

- Dispose of the cheek riser in accordance with local regulations regarding plastic waste.
- If the product is damaged or no longer usable, consider recycling it if facilities are available.

- Do not dispose of the product in regular household waste if it can be recycled.

Contact Information for Further Support

For further assistance, please refer to the manufacturer's website or contact your local retailer for support regarding the AK47 3/4" Cheek Riser.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities. Enjoy your shooting experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk