

AK-47 3/4" CHEEK RISER - MAGPUL AK CHEEK RISER 3/4" POLYMER FOR AK-47/74 GRAY

[Rifle Parts](#) > [Stock Parts](#) > [Stock Hardware](#) > [Cheek Pieces](#)

Tool-less clip-on cheek risers for the MOE AK and Zhukov-S Stocks. Gives the user the option to raise the cheek weld .75 inches in height. Will not interfere with storage access on MOE Stock or the folding mechanism on the Zhukov-S Stock.



Attributes

- Name: [MAGPUL AK CHEEK RISER 3/4" POLYMER FOR AK-47/74 GRAY](#)
- Manufacturer: [MAGPUL](#)
- Product no.: 100016662
- Mfr. No.: MAG447-GRY
- Finish: Gray
- Material: Polymer
- Weapon type: AK-47,AK-74
- Delivery weight: 0.07kg
- Shipping height: 38mm
- Shipping width: 32mm
- Shipping length: 178mm
- UPC: 840815100690

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- Startpage
- Safety Instruction Guide for AK47 3/4" Cheek Riser
- About Us

Safety Instruction Guide for AK47 3/4" Cheek Riser

Introduction

Thank you for purchasing the AK47 3/4" Cheek Riser by MAGPUL. This product is designed to enhance your shooting experience by providing an adjustable cheek weld for improved comfort and aim. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always ensure that the firearm is unloaded before installing or adjusting the cheek riser.
- Be aware of your surroundings and ensure a safe shooting environment.
- Follow all local laws and regulations regarding firearm accessories.
- Keep the product out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for product recalls on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure the cheek riser is securely attached before use to prevent it from detaching during operation.
- Do not exceed the recommended height adjustment of 0.75 inches.
- Avoid using the cheek riser with incompatible stocks or firearms.
- Inspect the cheek riser regularly for signs of wear or damage.
- Do not modify the cheek riser in any way, as this may compromise its safety and effectiveness.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded.
- Position the cheek riser against the stock of the firearm.
- Align the clip of the cheek riser with the designated attachment point on the stock.
- Press firmly until the clip snaps into place. Ensure it is securely attached.

2. Usage:

- Adjust the cheek riser to your desired height (up to 0.75 inches).
- Make sure the riser is stable and does not shift during use.
- Use the cheek riser to establish a consistent cheek weld for improved accuracy.

Disposal Instructions

- Dispose of the cheek riser responsibly. Do not discard it in regular household waste.
- Check local regulations for proper disposal methods for polymer materials.
- If the product is damaged beyond use, consider recycling options available in your area.

Contact Information for Further Support

For safety inquiries or additional support regarding the AK47 3/4" Cheek Riser, please refer to the manufacturer's website or contact their customer service directly.

Thank you for prioritizing safety while using the AK47 3/4" Cheek Riser. Your responsible use contributes to a

safer shooting community.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk