

AK-47 3/4" CHEEK RISER - MAGPUL AK CHEEK RISER 3/4" POLYMER FOR AK-47/74 ODG

[Rifle Parts](#) > [Stock Parts](#) > [Stock Hardware](#) > [Cheek Pieces](#)

Tool-less clip-on cheek risers for the MOE AK and Zhukov-S Stocks. Gives the user the option to raise the cheek weld .75 inches in height. Will not interfere with storage access on MOE Stock or the folding mechanism on the Zhukov-S Stock.



Attributes

- Name: [MAGPUL AK CHEEK RISER 3/4" POLYMER FOR AK-47/74 ODG](#)
- Manufacturer: [MAGPUL](#)
- Product no.: 100016663
- Mfr. No.: MAG447-ODG
- Finish: O.D. Green
- Material: Polymer
- Weapon type: AK-47,AK-74
- Delivery weight: 0.075kg
- Shipping height: 51mm
- Shipping width: 32mm
- Shipping length: 165mm
- UPC: 840815100706

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- [Startpage](#)
- [AK47 3/4" Cheek Riser Safety Instruction Guide](#)
- [About Us](#)

AK47 3/4" Cheek Riser Safety Instruction Guide

Introduction

Thank you for choosing the AK47 3/4" Cheek Riser by MAGPUL. This product is designed to enhance your shooting experience by providing an adjustable cheek weld. This safety instruction guide is intended to ensure your safe and effective use of the cheek riser, in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the cheek riser is compatible with your AK47 or AK74 model.
- Always inspect the product for any damage or defects before use.
- Keep the product out of reach of children and unauthorized users.
- Use the product only as intended and according to the instructions provided.
- Report any unsafe conditions or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Avoid using the cheek riser if it shows signs of wear or damage.
- Do not modify the cheek riser in any way.
- Ensure that the cheek riser is securely attached before each use to prevent accidents.
- Be aware of your surroundings when using the firearm equipped with the cheek riser.
- Use proper eye and ear protection while shooting.

Instructions for Installation and Usage

Installation

1. Preparation

- Ensure your firearm is unloaded and in a safe condition before installing the cheek riser.
- Gather all necessary tools if required for installation.

2. Attaching the Cheek Riser

- Align the cheek riser with the designated area on the MOE AK or ZhukovS Stock.
- Press the cheek riser into place until it clicks securely.
- Doublecheck that the riser is firmly attached and does not wobble.

3. Adjusting the Height

- To raise the cheek weld, simply pull the cheek riser upward to the desired height (0.75 inches).
- Ensure that the adjustment does not interfere with any storage access or folding mechanism.

Usage

- Once installed, position your cheek against the riser while aiming to ensure a comfortable and stable shooting position.
- Maintain a proper grip on the firearm and be mindful of the trigger at all times.

Disposal Instructions

- Dispose of the cheek riser in accordance with local regulations for plastic waste.

- Do not incinerate the product as it may release harmful substances.

Contact Information for Further Support

For further assistance, please refer to the manufacturer's website or customer service contact. Ensure you have your product details ready for efficient support.

Thank you for following these safety instructions. Your safety and the safety of others is our priority. Enjoy your shooting experience with the AK47 3/4" Cheek Riser!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk