

ADJUSTABLE REAR SIGHT FOR GLOCK® - L.P.A. SIGHTS

ADJUSTABLE BLACK REAR SIGHT

[Handgun Parts](#) > [Sights](#) > [Rear Sights](#)

The single adjustable rear sight which easily fits the most popular auto pistols without replacement of the factory front sight. By replacing the factory rear sight with a tpu, adjustable in windage and elevation with hardened click screws, you will convert your semi-auto into a modern firearm ready for target and practical shooting. Features: Works with the factory front sight. Fits the existing dovetail slot without milling work. Machined from solid steel using state-of-the-art cnc milling. Tapered dovetail for a better locking in the slide (install from left to right). Allen wrench and adjustment screw driver included in the package.



Attributes

- Name: [L.P.A. SIGHTS ADJUSTABLE BLACK REAR SIGHT](#)
- Manufacturer: [L.P.A. SIGHTS](#)
- Product no.: 100017334
- Mfr. No.: TPU32GL07
- Model: 18,19,23,26,29,32,34,35,21,22,17,20,27,28,31,25,30
- Sight Color: Black
- Style: U-Notch,Adjustable
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 5mm
- Shipping width: 155mm
- Shipping length: 107mm

Table of Contents

- Startpage
- Safety Instruction Guide for Adjustable Rear Sight for Glock® L.P.A. Sights
- About Us

Safety Instruction Guide for Adjustable Rear Sight for Glock® L.P.A. Sights

Introduction

Thank you for choosing the Adjustable Rear Sight for Glock® manufactured by L.P.A. SIGHTS. This guide provides essential safety instructions and information to ensure the proper use, installation, and disposal of your new sight. Please read this guide carefully to maximize safety and product performance.

General Safety Guidelines

- Always ensure that your firearm is unloaded before installing or adjusting the rear sight.
- Do not attempt to install or adjust the sight if you are unfamiliar with firearm components. Seek assistance from a qualified gunsmith if necessary.
- Keep the rear sight and all firearm components away from children and unauthorized individuals.
- Regularly inspect the sight for any signs of wear or damage. If any issues are detected, discontinue use and consult a professional.
- Use the sight only with the compatible Glock® models as specified in this guide.
- Be aware of your surroundings and ensure a safe shooting environment when using your firearm.

Specific Safety Precautions for Use

- Ensure that the factory front sight is properly installed and compatible with the adjustable rear sight.
- Avoid using the sight in extreme weather conditions or environments that may compromise its integrity.
- Do not modify the sight or attempt to disassemble it, as this may lead to malfunctions or unsafe conditions.
- Use the provided Allen wrench and adjustment screwdriver for installation and adjustments only; using other tools may result in damage.
- If you experience any malfunctions while using the sight, cease use immediately and have the firearm inspected by a qualified professional.

Instructions for Installation and Usage

1. Preparation:

- Ensure your firearm is completely unloaded.
- Gather the necessary tools: the provided Allen wrench and adjustment screwdriver.

2. Installation:

- Remove the existing factory rear sight from your Glock® model.
- Align the tapered dovetail of the adjustable rear sight with the existing dovetail slot on the slide.
- Install the adjustable rear sight from left to right to ensure proper locking.
- Secure the sight in place using the Allen wrench to tighten the screws. Ensure it is snug but do not overtighten.

3. Adjustment:

- To adjust windage (left or right), use the adjustment screwdriver to turn the designated screw.
- To adjust elevation (up or down), use the same screwdriver on the appropriate screw.
- Make small adjustments and test the sight at the range to ensure accuracy.

4. Usage:

- Once installed and adjusted, familiarize yourself with the sight's operation.
- Practice shooting in a safe environment to ensure comfortable and accurate use.

Disposal Instructions

- When disposing of the Adjustable Rear Sight, follow local regulations for metal recycling or disposal of firearm components.
- Do not throw the sight in regular household waste. Instead, take it to a designated recycling facility if available.

Contact Information for Further Support

For any questions or concerns regarding the Adjustable Rear Sight for Glock®, please reach out to the manufacturer or a qualified professional. Ensure you have the product details ready for reference.

This safety instruction guide is designed to ensure your safety and the proper functioning of your Adjustable Rear Sight for Glock® L.P.A. SIGHTS. By following these guidelines, you can enjoy the benefits of your new sight while minimizing risks. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk