

COLT ADJUSTABLE REAR SIGHT - L.P.A. SIGHTS COLT A1 DOVETAIL ADJUSTABLE REAR SIGHT

[Handgun Parts](#) > [Sights](#) > [Rear Sights](#)

The single adjustable rear sight which easily fits the most popular auto pistols without replacement of the factory front sight. By replacing the factory rear sight with a tpu, adjustable in windage and elevation with hardened click screws, you will convert your semi-auto into a modern firearm ready for target and practical shooting. Features: Works with the factory front sight. Fits the existing dovetail slot without milling work. Machined from solid steel using state-of-the-art cnc milling. Tapered dovetail for a better locking in the slide (install from left to right). Allen wrench and adjustment screw driver included in the package.



Attributes

- Name: [L.P.A. SIGHTS COLT A1 DOVETAIL ADJUSTABLE REAR SIGHT](#)
- Manufacturer: [L.P.A. SIGHTS](#)
- Product no.: 100017336
- Mfr. No.: TPU45CT07
- Sight Color: Black
- Style: Adjustable,U-Notch
- Weapon type: Colt
- Delivery weight: 0.045kg
- Shipping height: 5mm
- Shipping width: 155mm
- Shipping length: 104mm

Table of Contents

- Startpage
- Safety Instruction Guide for COLT Adjustable Rear Sight
- About Us

Safety Instruction Guide for COLT Adjustable Rear Sight

Introduction

Thank you for choosing the COLT Adjustable Rear Sight from L.P.A. SIGHTS. This guide provides important safety instructions and recommendations to ensure the safe and effective use of your new sight. Please read this guide carefully before installation and use.

General Safety Guidelines

- Ensure the sight is compatible with your firearm before installation.
- Always handle firearms safely and responsibly.
- Keep the sight and all firearm accessories out of reach of children and unauthorized users.
- Regularly inspect the sight for any signs of wear or damage.
- Report any unsafe products or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always follow the manufacturer's instructions for installation and use.
- Ensure the firearm is unloaded before installing the sight.
- Check that the sight is securely mounted before use.
- Use appropriate eye and ear protection when shooting.
- Be aware of your surroundings and ensure a safe shooting environment.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: an Allen wrench and adjustment screwdriver (included).

2. Installation:

- Remove the factory rear sight from the dovetail slot of your firearm.
- Align the tapered dovetail of the COLT Adjustable Rear Sight with the existing dovetail slot.
- Install the sight from left to right, ensuring it is properly seated.
- Secure the sight using the hardened click screws provided.
- Adjust the windage and elevation as needed using the included adjustment tools.

3. Usage:

- Once installed, test the sight for proper alignment.
- Make any necessary adjustments before proceeding to shoot.
- Regularly check the sight for tightness and alignment during use.

Disposal Instructions

- Dispose of the product responsibly in accordance with local regulations.
- Do not dispose of the sight in household waste.
- Check with local authorities for proper disposal methods for firearm accessories.

Contact Information for Further Support

For any questions or concerns regarding the COLT Adjustable Rear Sight, please refer to the manufacturer's contact information provided with your product packaging or visit their official website.

Thank you for your attention to these safety guidelines. Enjoy your shooting experience with the COLT Adjustable Rear Sight!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk