

VICKERS TACTICAL SLIDE STOP FOR GLOCK® 42/43 - TANGODOWN

VICKERS TACTICAL SLIDE STOP FOR GLOCK® 42/43

[Handgun Parts](#) > [Frame Parts](#) > [Slide Catch Parts](#) > [Slide Catches](#)

Small pistols can present big problems under stress reloads. On top of limited magazine capacity, undersized controls can hamper-or even prevent-a proper reload. The stakes are clear in that event. Don't run the risk....install a Vickers Tactical Slide Stop. It features the same positive V-shape with deep serrations that enables fast manipulation, in both directions, found on the original VT Slide Stop. A huge improvement to the Glock 42 and 43. Fits Glock Model 42 and 43. Will not fit Glock Models 25 or 28. Reshaped thumb pad with deep serrations, allows easy slide lock and release, even with gloves. Precision stamped from 4130 chrome moly steel, with non-glare black finish.



Attributes

- Name: [TANGODOWN VICKERS TACTICAL SLIDE STOP FOR GLOCK® 42/43](#)
- Manufacturer: [TANGODOWN](#)
- Product no.: 100017672
- Mfr. No.: VTSS-002
- Caliber: 38/357 Caliber (.357-.359),9 mm (.355-.356)
- Finish: Black
- Model: 42,43
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 23mm
- Shipping width: 69mm
- Shipping length: 140mm
- UPC: 955727100604

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Vickers Tactical Slide Stop for Glock® 42/43 Safety Instruction Guide
- About Us

Vickers Tactical Slide Stop for Glock® 42/43 Safety Instruction Guide

Introduction

Thank you for choosing the Vickers Tactical Slide Stop for your Glock® 42 or 43. This guide provides essential safety instructions and information to ensure safe and effective use of the product. Please read this document carefully before installation and usage.

General Safety Guidelines

- Ensure that the product is compatible with your firearm model. The Vickers Tactical Slide Stop is specifically designed for Glock® Model 42 and 43. It will not fit Glock Models 25 or 28.
- Always handle firearms with care and follow basic gun safety rules.
- Keep the slide stop and any firearm components away from children and unauthorized users.
- Regularly inspect the slide stop for wear or damage. If you notice any issues, discontinue use and contact a qualified gunsmith.
- Report any unsafe products or accidents to the relevant authorities and check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded before installing or handling the slide stop.
- Use gloves when manipulating the slide stop to prevent accidental injury.
- Be cautious when performing reloads, especially under stress, to avoid mishandling.
- Do not attempt to modify the slide stop or firearm components; alterations may compromise safety.
- Familiarize yourself with the operation of the slide stop before use to ensure proper handling.

Instructions for Installation and Usage

Installation Steps

1. **Ensure Safety:** Confirm that your Glock® 42 or 43 is unloaded and pointed in a safe direction.
2. **Remove the Factory Slide Stop:**
 - Use a punch or appropriate tool to push out the retaining pin that holds the factory slide stop in place.
 - Carefully remove the factory slide stop from the firearm.
3. **Install the Vickers Tactical Slide Stop:**
 - Align the new slide stop with the corresponding slot in the firearm.
 - Insert the new slide stop into the slot.
 - Replace the retaining pin to secure the slide stop in place.
4. **Test Functionality:**
 - Manually operate the slide stop to ensure it engages and releases smoothly.
 - Doublecheck that the slide stop is securely installed before using the firearm.

Usage Instructions

- To lock the slide open, pull the slide back and engage the slide stop.
- To release the slide, press down on the slide stop with your thumb.
- Practice using the slide stop in a safe environment to become familiar with its operation.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the slide stop is damaged beyond use, ensure it is disposed of in a manner that prevents accidental injury to others.

Contact Information for Further Support

For any inquiries regarding safety, installation, or usage of the Vickers Tactical Slide Stop, please consult the manufacturer's website or contact a qualified gunsmith for assistance.

By following these instructions and guidelines, you can ensure the safe and effective use of the Vickers Tactical Slide Stop for your Glock® 42 or 43. Thank you for prioritizing safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk