

VICKERS TACTICAL SLIDE RACKER - TANGODOWN VICKERS TACTICAL SLIDE RACKER-GLOCK 42 ONLY

[Handgun Parts](#) > [Slide Parts](#) > [Slide Hardware](#) > [Slide Rackers](#)

The GSR-03 adds subtle, but tractable serrated wings at the slide's end, to guarantee a positive cycling of ammunition into the weapon. No matter how adverse the conditions, or how tough the fight, you can always rely on the GSR-03 to keep your weapon up and running. Even if you're down to one hand, cycling the slide against your belt, holster or heel is quick and positive. Small or arthritic hands will find it much easier to use than the traditional 'slingshot' method. The GSR-03 is big enough to offer advantage, yet small enough to be unnoticeable in concealed carry holsters. The GSR-03 is a top quality drop-in part, requiring no other modifications to the firearm. Injection molded of glass-reinforced nylon with stainless steel reinforcement just like the OEM part, it replaces the striker retention plate in minutes. Once in place, the GSR-03 offers easy, effortless and positive slide cycling under any condition. Tough, stainless steel & injection molded glass reinforced nylon construction



Attributes

- Name: [TANGODOWN VICKERS TACTICAL SLIDE RACKER-GLOCK 42 ONLY](#)
- Manufacturer: [TANGODOWN](#)
- Product no.: 100017977
- Mfr. No.: GSR01
- Model: 42
- Weapon type: Glock
- Delivery weight: 0.016kg
- Shipping height: 38mm
- Shipping width: 83mm
- Shipping length: 140mm
- UPC: 955728100733

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Vickers Tactical Slide Racker Safety Instructions
- About Us

Vickers Tactical Slide Racker Safety Instructions

Introduction

Thank you for choosing the Vickers Tactical Slide Racker for your Glock 42. This product is designed to enhance the functionality of your firearm while ensuring safety during use. Please read this safety instruction guide carefully to understand how to use the Slide Racker safely and effectively.

General Safety Guidelines

- Ensure that all firearms are handled with care and respect.
- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Before installation or use, ensure that the firearm is unloaded.
- Store the Slide Racker and your firearm in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the Slide Racker and your firearm for signs of wear or damage.
- Do not use the Slide Racker if it appears damaged or does not fit properly.

Specific Safety Precautions for Use

- Always wear appropriate eye protection when using your firearm.
- Avoid using the Slide Racker in wet or slippery conditions to prevent loss of grip.
- If you experience difficulty cycling the slide, do not force it. Check for proper installation and functionality.
- Use only with Glock 42 models; do not attempt to use with other models or brands.
- Be aware of your surroundings and ensure that you have a clear shooting area before using your firearm.
- If you are new to firearms, seek instruction from a qualified professional before use.

Instructions for Installation and Usage

Installation

1. **Unload Your Firearm:** Ensure your Glock 42 is completely unloaded.
2. **Remove the Striker Retention Plate:** Using the appropriate tools, carefully remove the existing striker retention plate from your firearm.
3. **Install the GSR03 Slide Racker:** Align the GSR03 Slide Racker with the installation slot and press it into place until it clicks securely.
4. **Reassemble Your Firearm:** Ensure all parts are reassembled correctly and securely.
5. **Test Functionality:** Cycle the slide to ensure the Slide Racker is functioning properly.

Usage

- To cycle the slide, use your thumb to engage the serrated wings of the Slide Racker.
- If using one hand, press the Slide Racker against your belt, holster, or heel for a firm grip.
- Practice using the Slide Racker in a safe environment until you are comfortable with its operation.

Disposal Instructions

- Dispose of the Slide Racker in accordance with local regulations.
- Do not dispose of the Slide Racker in regular household waste.
- Contact your local waste management authority for guidance on proper disposal.

Contact Information for Further Support

For any inquiries or support regarding the Vickers Tactical Slide Racker, please refer to the manufacturer's contact details provided with your product packaging.

Conclusion

The Vickers Tactical Slide Racker is a valuable accessory for your Glock 42, designed to enhance your shooting experience while ensuring safety. By following these guidelines and instructions, you can use the Slide Racker effectively and responsibly. Always prioritize safety and seek professional assistance if needed.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk