

AK-47/74 BRAIDED MAIN SPRING - ALG DEFENSE AK-47/74 BRAIDED MAIN SPRING

[Rifle Parts](#) > [Receiver Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

The ALG AK Braided Main Spring is a replacement spring for the AK47/74 platform rifles. This replacement option is manufactured in the United States from three strands of music wire braided together.



Attributes

- Name: [ALG DEFENSE AK-47/74 BRAIDED MAIN SPRING](#)
- Manufacturer: [ALG DEFENSE](#)
- Product no.: 100018971
- Mfr. No.: 04-232-F
- Weapon type: AK-47,AK-74
- Delivery weight: 0.011kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 108mm
- UPC: 817953021910

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AK47/74 Braided Main Spring
- About Us

Safety Instruction Guide for AK47/74 Braided Main Spring

Introduction

Thank you for choosing the ALG AK47/74 Braided Main Spring. This replacement spring is designed specifically for the AK47/74 platform rifles, providing enhanced performance and reliability. It is essential to follow the safety guidelines and instructions in this manual to ensure safe usage and optimal performance of your product.

General Safety Guidelines

- Always ensure that the firearm is unloaded before performing any maintenance or installation of the spring.
- Store the spring in a cool, dry place away from direct sunlight and moisture.
- Inspect the spring regularly for signs of wear or damage. Replace immediately if any issues are detected.
- Use only compatible firearms with the ALG AK47/74 Braided Main Spring. Ensure that your rifle is designed for use with this specific replacement spring.
- Keep the spring and all firearm components out of reach of children and unauthorized individuals.
- Report any unsafe conditions, accidents, or product malfunctions to the appropriate authorities.

Specific Safety Precautions for Use

- Handle the spring with care. The braided music wire can pose a risk of injury if mishandled.
- When installing or removing the spring, wear protective gloves and safety goggles to prevent injury.
- Ensure that all tools used during installation are appropriate for the task and in good condition.
- Do not attempt to modify or alter the spring in any way, as this may compromise its safety and performance.
- Follow all local laws and regulations regarding firearm modifications and maintenance.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your firearm is completely unloaded and in a safe condition.
- Gather all necessary tools, including a screwdriver and any other tools required for your specific firearm model.

2. Installation Steps:

- Remove the existing main spring from the firearm, following the manufacturer's instructions.
- Inspect the spring housing for any debris or damage. Clean if necessary.
- Carefully insert the ALG AK47/74 Braided Main Spring into the spring housing, ensuring it is seated properly.
- Reassemble the firearm according to the manufacturer's guidelines, ensuring all parts are secure.

3. Usage:

- After installation, conduct a function check to confirm that the firearm operates correctly.
- If any issues arise during the function check, disassemble the firearm and recheck the installation of the spring.
- Always follow safe handling practices when using the firearm.

Disposal Instructions

- Dispose of the spring in accordance with local regulations regarding metal waste.
- Do not dispose of the spring in regular household waste. Instead, take it to a designated recycling facility or metal scrap yard.

Contact Information for Further Support

For any questions or concerns regarding the ALG AK47/74 Braided Main Spring, please consult with your local dealer or manufacturer for assistance. Ensure that you have all relevant product information available when seeking support.

By following these safety guidelines and instructions, you will help ensure a safe and effective experience with your ALG AK47/74 Braided Main Spring. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk