

1911 AUTO MAXBEVEL MAINSPRING HOUSING - STAN CHEN CUSTOMS 1911 AUTO MAXBEVEL MAINSPRING HOUSING, 25 LPI, BLUED

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainspring Housings](#)

Larger Magazine Well Bevel for Faster Reloads with No Extra Bulk Unique design allows the custom gunsmith to seamlessly cut the bevel of the magwell back into the mainspring housing, allowing a much larger magwell opening without an add on magwell. Proprietary BevelBlock™ fitting block of extra material on the front ledge of the mainspring housing forms a seamless butt joint with the frame, deep into the frame's magazine well. The BevelBlock now comes pre-machined with an angled rear bevel to make installation even simpler, while still allowing the gunsmith to shape to their own profile, if desired. Allows shooters to hit the sweet spot at the rear of the magwell during combat reloads. Machined to maximum dimensions to deliver a nice snug fit in most 1911 frames without excessive material removal. Perfect for carry applications to greatly increase the magwell opening with no extra bulk. Requires one simple machine cut for installation before final shaping. Available in flat and smooth, or custom quality checkered at 20, 25 or 30 lines per inch by master metalsmith Pete Single. Perfectly formed diamonds improve grip and control during rapid fire. Rounded heel increases shooting and carry comfort. Precision machined from tough, solid barstock for extreme durability.



Attributes

- Name: [STAN CHEN CUSTOMS 1911 AUTO MAXBEVEL MAINSPRING HOUSING, 25 LPI, BLUED](#)
- Manufacturer: [STAN CHEN CUSTOMS](#)
- Product no.: 100019366
- Mfr. No.: CMSH-25-BL
- Finish: Blued
- Model: -
- Weapon type: 1911
- Delivery weight: 0.118kg
- Shipping height: 32mm
- Shipping width: 152mm
- Shipping length: 229mm

Item details

Made in USA
US export classification: 0A501.y.1

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 AUTO MAXBEVEL MAINSPRING HOUSING
- About Us

Safety Instruction Guide for 1911 AUTO MAXBEVEL MAINSPRING HOUSING

Introduction

Thank you for choosing the 1911 AUTO MAXBEVEL MAINSPRING HOUSING by STAN CHEN CUSTOMS. This product is designed to enhance your 1911 pistol's performance while ensuring safety and reliability. Please read this safety instruction guide carefully to ensure proper usage and installation.

General Safety Guidelines

- Ensure that all firearms are handled with care and stored safely when not in use.
- Always treat every firearm as if it is loaded.
- Keep firearms pointed in a safe direction at all times.
- Store ammunition separately from firearms.
- Regularly inspect your firearm and components for wear or damage.
- Follow all local laws and regulations regarding firearm ownership and usage.
- Report any unsafe products or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Installation Warning:** Gunsmith installation is recommended to ensure proper fitting and safety. Improper installation may lead to malfunctions or safety hazards.
- **Bevel Block Caution:** The BevelBlock™ fitting block is designed for a snug fit; ensure it is correctly aligned to avoid any misfit during installation.
- **Handling Precautions:** Always handle the mainspring housing with care to prevent any accidental discharge during installation.
- **Age Warning:** This product is intended for use by adults only. Keep out of reach of children.
- **Combat Reloads:** Practice combat reloads in a safe environment before using this product in a live situation.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your firearm is unloaded before beginning installation.
- Gather the necessary tools for installation, including a precision cutter and measuring tools.

2. Installation Steps:

- Remove the existing mainspring housing from your 1911 frame.
- Align the 1911 AUTO MAXBEVEL MAINSPRING HOUSING with the frame, ensuring that the BevelBlock™ fitting block is properly seated.
- Make one simple machine cut as required for installation before final shaping.
- Shape the rear bevel to your desired profile if necessary, using the premachined angled rear bevel as a guide.
- Reassemble your firearm carefully, ensuring all components are secure.

3. Usage Tips:

- After installation, practice reloading with the new magwell opening to familiarize yourself with the changes.
- Regularly check the fit and condition of the mainspring housing to ensure ongoing safety and

performance.

Disposal Instructions

- Dispose of any packaging materials in accordance with local recycling regulations.
- If the product is damaged beyond use, follow local guidelines for the disposal of metal and firearm components.

Contact Information for Further Support

For any questions or concerns regarding the installation, usage, or safety of the 1911 AUTO MAXBEVEL MAINSPRING HOUSING, please reach out to your local firearms expert or gunsmith.

Thank you for prioritizing safety in your firearm usage. Enjoy the enhanced performance of your 1911 AUTO MAXBEVEL MAINSPRING HOUSING.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk