

TOP PUNCHES - SAEKO #24243 TOP PUNCH

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

SAEKO's exclusive tapered shoulder assures positive alignment with the die body. A single Top Punch may be used interchangeably with several bullets of similar design.



Attributes

- Name: [SAEKO #24243 TOP PUNCH](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020283
- Mfr. No.: 24243
- Delivery weight: 0.005kg
- Shipping height: 7mm
- Shipping width: 76mm
- Shipping length: 128mm
- UPC: 611760242434

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES SAEKO #24243
- About Us

Safety Instruction Guide for TOP PUNCHES SAEKO #24243

Introduction

Thank you for choosing the TOP PUNCHES SAEKO #24243. This safety instruction guide is designed to ensure safe and effective use of the product. Please read this guide carefully before using the product to understand its features and safety precautions.

General Safety Guidelines

- Always follow the manufacturer's instructions for use.
- Ensure the workspace is clean and free from any hazards before starting.
- Use the product only for its intended purpose; do not modify or misuse it.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE) such as safety goggles and gloves when using the product.
- Ensure that all parts of the product are securely attached before use.
- Do not exceed the recommended load limits when using the product.
- Avoid using the product in wet or damp conditions to prevent electric shock or other hazards.
- If you experience any discomfort or unusual sensations while using the product, stop immediately and seek assistance.

Instructions for Installation and Usage

1. Installation:

- Ensure that the work area is stable and welllit.
- Place the die body on a flat surface.
- Align the tapered shoulder of the Top Punch with the die body to ensure proper fit.
- Secure the Top Punch in place according to the manufacturer's instructions.

2. Usage:

- Before starting, doublecheck that all components are properly aligned.
- Use the Top Punch to perform the intended operation, ensuring that you maintain a firm grip.
- Do not force the Top Punch; if it does not move smoothly, stop and check for obstructions or misalignment.
- After use, carefully remove the Top Punch from the die body and store it in a safe place.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is damaged or no longer usable, consider recycling options where available.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's contact details provided with the product packaging.

By adhering to these safety guidelines and instructions, you can ensure a safe and effective experience with the TOP PUNCHES SAEKO #24243. Thank you for prioritizing safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk