

TOP PUNCHES - SAEKO #44428 TOP PUNCH

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

SAEKO's exclusive tapered shoulder assures positive alignment with the die body. A single Top Punch may be used interchangeably with several bullets of similar design.



Attributes

- Name: [SAEKO #44428 TOP PUNCH](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020301
- Mfr. No.: 44428
- Delivery weight: 0.068kg
- UPC: 611760444289

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES SAEKO #44428
- About Us

Safety Instruction Guide for TOP PUNCHES SAEKO #44428

Introduction

Thank you for choosing the TOP PUNCHES SAEKO #44428. This guide provides essential safety instructions to ensure the safe use and handling of your product. Please read this document carefully before using the product to avoid any potential hazards.

General Safety Guidelines

- Ensure that the product is used in accordance with the manufacturer's instructions.
- Always inspect the product for any signs of damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose as described in this guide.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as gloves and safety glasses when using the Top Punch.
- Ensure that the work area is clean, dry, and welllit to prevent accidents.
- Do not use the Top Punch if it appears to be damaged or malfunctioning.
- Avoid using excessive force when operating the Top Punch to prevent injury or damage.
- Keep hands and other body parts clear of the die body during operation to avoid pinching or crushing injuries.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials before starting.
- Ensure that the die body is properly secured and stable.

2. Installation:

- Align the tapered shoulder of the Top Punch with the die body.
- Insert the Top Punch into the die body, ensuring it is firmly seated.
- Verify that the Top Punch is correctly aligned and locked in position.

3. Usage:

- Operate the die according to the manufacturer's instructions.
- Monitor the operation closely to ensure safe and effective use.
- If any issues arise during operation, stop immediately and inspect the product.

4. PostUse:

- After use, remove the Top Punch from the die body.
- Clean the Top Punch and die body to remove any debris or residue.
- Store the Top Punch in a safe and dry location, away from children.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available.

Contact Information for Further Support

For any inquiries related to product safety or usage, please refer to the contact information provided with the product packaging or visit the manufacturer's website.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu