

TOP PUNCHES - SAEKO #44944 TOP PUNCH

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

SAEKO's exclusive tapered shoulder assures positive alignment with the die body. A single Top Punch may be used interchangeably with several bullets of similar design.



Attributes

- Name: [SAEKO #44944 TOP PUNCH](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020302
- Mfr. No.: 44944
- Delivery weight: 0.023kg
- UPC: 611760449444

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES SAEKO #44944
- About Us

Safety Instruction Guide for TOP PUNCHES SAEKO #44944

Introduction

Thank you for choosing the TOP PUNCHES SAEKO #44944. This guide provides essential safety instructions to ensure safe usage and maintenance of the product. Please read this guide carefully before using the product to prevent any accidents and ensure optimal performance.

General Safety Guidelines

- Always use the product according to the manufacturer's instructions.
- Inspect the product for any damage before use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Ensure proper supervision when using the product in environments with children.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform regularly.

Specific Safety Precautions for Use

- Always ensure that the Top Punch is securely attached to the die body before use.
- Do not attempt to modify the Top Punch or use it for purposes other than intended.
- Wear appropriate personal protective equipment (PPE) such as gloves and safety glasses when handling the Top Punch.
- Avoid using excessive force when operating the Top Punch to prevent injury or damage.
- Ensure that your workspace is clean and free from clutter to minimize the risk of accidents.

Instructions for Installation and Usage

1. Installation:

- Ensure the die body is clean and free from debris.
- Align the tapered shoulder of the Top Punch with the die body.
- Gently insert the Top Punch into the die body until it is securely in place.
- Verify that the Top Punch is properly aligned before proceeding.

2. Usage:

- Carefully operate the die according to the provided instructions.
- Monitor the Top Punch during use for any signs of wear or damage.
- If the Top Punch becomes stuck or difficult to remove, do not force it. Instead, consult the manufacturer for guidance.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options for metal components where applicable.

Contact Information for Further Support

For any safety inquiries or support regarding the TOP PUNCHES SAEKO #44944, please refer to the

manufacturer's contact information provided with the product packaging.

Thank you for your attention to these safety instructions. Your safety is our priority.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu