

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #2424

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #2424](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020313
- Mfr. No.: 46501
- Delivery weight: 0.068kg
- Shipping width: 76mm
- Shipping length: 128mm
- UPC: 611760465017

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #2424
- About Us

Safety Instruction Guide for TOP PUNCHES

LYMAN/RCBS STYLE SAEKO TOP PUNCHES

LYMAN/RCBS TYPE #2424

Introduction

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #2424. This guide provides important safety information and instructions to ensure safe and effective use of this product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose, which is to fit Lyman and RCBS Lubrisizers and SAEKO bullets.
- Keep the product out of reach of children and vulnerable individuals to prevent accidental injury.
- Regularly inspect the product for signs of wear or damage. Do not use if damaged.
- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling or using this product.
- Follow all relevant local laws and regulations regarding the use of such tools and equipment.

Specific Safety Precautions for Use

- Do not exceed the recommended capacity or specifications of the top punches.
- Use the product in a wellventilated area to avoid inhalation of any dust or particles generated during use.
- Avoid contact with sharp edges or moving parts to prevent cuts or injuries.
- Ensure that the work area is clean and free from obstacles to prevent tripping or falling hazards.
- Do not modify the product in any way, as this may compromise safety and effectiveness.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Lubrisizer is powered off and unplugged before installation.
- Align the straight shank of the top punch with the mounting hole of the Lubrisizer.
- Securely fasten the top punch in place according to the Lubrisizer's manufacturer instructions.

2. Usage:

- Before using the top punch, verify that it is securely installed.
- Load the appropriate SAEKO bullets into the Lubrisizer as per the manufacturer's guidelines.
- Operate the Lubrisizer according to its instructions, ensuring that the top punch is correctly positioned to avoid misalignment.
- After use, clean the top punch and Lubrisizer to maintain performance and safety.

Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous waste.
- Do not dispose of the product in regular household waste.
- For specific disposal methods, consult your local waste management authority.

Contact Information for Further Support

For any safety inquiries or further assistance, please refer to the EU contact point relevant to your location. Check the EU Safety Gate platform for updates on recalls or safety notices related to this product.

By adhering to the guidelines and instructions outlined in this document, you can ensure a safe and effective experience with the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #2424. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk