

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3025

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3025](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020314
- Mfr. No.: 46507
- Delivery weight: 0.045kg
- Shipping width: 76mm
- Shipping length: 120mm
- UPC: 611760465079

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3025
- About Us

Safety Instruction Guide for TOP PUNCHES

LYMAN/RCBS STYLE SAEKO TOP PUNCHES

LYMAN/RCBS TYPE #3025

Introduction

Thank you for purchasing the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3025. This product is designed to enhance your reloading experience with compatibility for Lyman and RCBS Lubrisizers and SAEKO bullets. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always use the product according to the manufacturer's instructions.
- Inspect the product before each use for any signs of wear or damage.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the top punch is securely attached to the lubrisizer before use.
- Do not exceed the recommended pressure settings during operation to avoid damage or injury.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when handling the product.
- Avoid using the product in wet or damp areas to prevent electrical hazards if using powered lubrisizers.
- Do not modify or alter the product in any way, as this may compromise safety and performance.

Instructions for Installation and Usage

1. Installation:

- Ensure the lubrisizer is powered off and unplugged before installation.
- Select the appropriate top punch for your specific SAEKO bullet type.
- Align the top punch with the lubrisizer's punch holder.
- Secure the top punch by tightening the set screw until it is firmly in place.

2. Usage:

- Prepare your bullets and lubrisizer according to your reloading process.
- Power on the lubrisizer and set the desired pressure settings.
- Place the bullets in the lubrisizer and operate according to the manufacturer's instructions.
- Monitor the operation closely to ensure everything functions correctly and safely.

3. PostUse Care:

- After use, turn off and unplug the lubrisizer.
- Clean the top punch and lubrisizer according to the manufacturer's recommendations.
- Store the product in a dry, safe place away from children and pets.

Disposal Instructions

- Dispose of the product in accordance with local regulations for nonfood products.
- Do not dispose of the product in household waste if it contains any hazardous materials.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any questions or concerns regarding the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3025, please refer to the manufacturer's website or contact their customer service for assistance.

Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation. Enjoy your reloading experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk