

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3555

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3555](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020323
- Mfr. No.: 46525
- Delivery weight: 0.045kg
- Shipping height: 6mm
- Shipping width: 76mm
- Shipping length: 115mm
- UPC: 611760465253

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3555
- About Us

Safety Instruction Guide for TOP PUNCHES

LYMAN/RCBS STYLE SAEKO TOP PUNCHES

LYMAN/RCBS TYPE #3555

Introduction

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3555. This guide provides essential safety instructions and usage information to ensure your safety and the proper functioning of the product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Always inspect the product for any signs of damage before use.
- Do not use the product if it appears defective or damaged.
- Follow all local regulations regarding the use and disposal of this product.

Specific Safety Precautions for Use

- Use protective eyewear and gloves when handling the top punches.
- Ensure that the workspace is clean and free from obstructions.
- Always secure the top punch properly in the lubrisizer before use.
- Avoid placing fingers near moving parts during operation.
- Do not attempt to modify or repair the product unless authorized by the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure that the lubrisizer is unplugged and not in operation.
- Select the appropriate top punch for your SAEKO bullets.
- Insert the top punch into the lubrisizer, ensuring it is seated securely.
- Tighten any screws or fasteners to hold the top punch in place.

2. Usage:

- Plug in the lubrisizer and turn it on.
- Load the SAEKO bullets into the lubrisizer as per the manufacturer's instructions.
- Operate the lubrisizer according to the guidelines provided in its manual.
- Monitor the operation closely to ensure safety and proper functioning.

3. PostUsage:

- Turn off and unplug the lubrisizer after use.
- Carefully remove the top punch and clean it according to the maintenance instructions.
- Store the top punch in a safe, dry place away from children.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.

- If the product is no longer usable, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support, please refer to the manufacturer's contact information provided with the product packaging or visit the manufacturer's website for more details.

Conclusion

Your safety is our priority. By following these guidelines, you can ensure a safe and effective experience with the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #3555. If you have any concerns or questions, please seek further assistance as needed.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk