

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4004

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4004](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020326
- Mfr. No.: 46529
- Delivery weight: 0.091kg
- Shipping height: 10mm
- Shipping width: 76mm
- Shipping length: 128mm
- UPC: 611760465291

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4004
- About Us

Safety Instruction Guide for TOP PUNCHES

LYMAN/RCBS STYLE SAEKO TOP PUNCHES

LYMAN/RCBS TYPE #4004

Introduction

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4004. This product is designed to fit Lyman and RCBS Lubrisizers and SAEKO bullets. Please read this safety instruction guide carefully to ensure safe use and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product regularly for any signs of damage or wear.
- Do not attempt to modify or repair the product yourself.
- Report any unsafe conditions or incidents to the relevant authorities.
- Check the EU Safety Gate platform regularly for recall updates.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) when using this product, such as gloves and safety glasses.
- Ensure that the workspace is clean and free from clutter to prevent accidents.
- Use the product in a wellventilated area to avoid inhalation of any fumes or particles.
- Do not use the product if you are under the influence of drugs or alcohol.
- Follow the manufacturer's instructions for use to avoid potential hazards.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Lyman or RCBS Lubrisizer is unplugged and cooled down before installation.
- Select the appropriate SAEKO top punch for your specific bullet type.
- Align the top punch with the Lubrisizer's ram and insert it securely.
- Tighten the top punch according to the manufacturer's specifications to ensure a secure fit.

2. Usage:

- Prepare your bullets and ensure they are clean and free from debris.
- Adjust the Lubrisizer settings according to the manufacturer's instructions.
- Insert the bullets into the Lubrisizer and engage the mechanism to apply lubricant.
- Monitor the process to ensure that the bullets are being lubricated evenly.
- After use, clean the top punch and Lubrisizer to maintain performance.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste.
- Consider recycling options for any metal components where applicable.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and use of this product, please refer to the manufacturer's contact point in the EU.

By following these safety instructions, you can ensure a safe and effective experience with the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4004. Always prioritize safety and compliance with relevant regulations. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk