

# **TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4041**

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



## **Attributes**

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4041](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020327
- Mfr. No.: 46532
- Delivery weight: 0.045kg
- Shipping height: 5mm
- Shipping width: 76mm
- Shipping length: 120mm
- UPC: 611760465321

## **Item details**

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4041
- About Us

# **Safety Instruction Guide for TOP PUNCHES**

## **LYMAN/RCBS STYLE SAEKO TOP PUNCHES**

## **LYMAN/RCBS TYPE #4041**

### **Introduction**

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE. This product is designed for use with Lyman and RCBS Lubrisizers and SAEKO bullets. To ensure safe and effective use, please read this safety instruction guide carefully. It contains important information regarding the safe handling, installation, and disposal of this product.

### **General Safety Guidelines**

- Always read and understand the instructions before using the product.
- Keep this product out of reach of children and vulnerable individuals.
- Inspect the product for any damage or defects before use. Do not use if damaged.
- Use the product only for its intended purpose as specified in this guide.
- If you encounter any issues or have questions, seek assistance before proceeding.

### **Specific Safety Precautions for Use**

- Ensure that the work area is clean, dry, and welllit to avoid accidents.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using this product.
- Avoid contact with moving parts during operation to prevent injury.
- Do not exceed the manufacturer's recommended specifications for use.
- Store the product in a safe and secure location when not in use.

### **Instructions for Installation and Usage**

#### **1. Installation**

- Ensure that the Lubrisizer is turned off and unplugged before installation.
- Select the appropriate top punch for the SAEKO bullet you are using.
- Align the top punch with the Lubrisizer's mounting area.
- Secure the top punch in place according to the manufacturer's instructions.

#### **2. Usage**

- Plug in and power on the Lubrisizer.
- Follow the manufacturer's guidelines for adjusting the Lubrisizer settings.
- Carefully load the SAEKO bullets into the Lubrisizer.
- Monitor the operation to ensure that everything is functioning correctly.
- After use, turn off and unplug the Lubrisizer.

### **Disposal Instructions**

- Dispose of the product in accordance with local regulations.
- Do not dispose of this product with regular household waste.
- If the product is damaged or no longer usable, contact your local waste management authority for proper disposal methods.

## **Contact Information for Further Support**

For any inquiries regarding safety, usage, or product issues, please contact your retailer or the manufacturer directly.

By following these safety instructions, you can ensure a safer experience while using the TOP PUNCHES LYMAN/RCBS STYLE. Thank you for your attention to these important guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)