

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4141

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4141](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020328
- Mfr. No.: 46534
- Delivery weight: 0.068kg
- Shipping height: 12mm
- Shipping width: 76mm
- Shipping length: 128mm
- UPC: 611760465345

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4141
- About Us

Safety Instruction Guide for TOP PUNCHES

LYMAN/RCBS STYLE SAEKO TOP PUNCHES

LYMAN/RCBS TYPE #4141

Introduction

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4141. This product is designed to fit Lyman and RCBS Lubrisizers and is intended for use with SAEKO bullets. To ensure your safety and the safety of others, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that you are using the product in accordance with the manufacturer's instructions.
- Always inspect the top punches for any signs of damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Do not use the product for any purpose other than its intended use.
- Report any unsafe product conditions or accidents to the appropriate authorities.
- Stay informed about recall updates via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including gloves and eye protection, when handling the product.
- Use the top punches only with compatible Lyman and RCBS Lubrisizers.
- Ensure that the top punches are securely attached before operation to prevent any accidents.
- Avoid using excessive force during operation to prevent damage to the product or injury.
- Do not modify the product in any way, as this can lead to unsafe conditions.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Lubrisizer is unplugged and not in operation.
- Locate the top punch mounting area on the Lubrisizer.
- Align the straight shank of the top punch with the mounting area.
- Securely attach the top punch using the appropriate fastening mechanism as per the Lubrisizer's manual.

2. Usage:

- Plug in the Lubrisizer and ensure it is functioning properly.
- Load the SAEKO bullets into the Lubrisizer as per the manufacturer's instructions.
- Operate the Lubrisizer according to the guidelines provided in its manual.
- Monitor the operation closely to ensure that everything is functioning safely.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding nonfood product waste.
- Do not dispose of the product in household waste if it contains hazardous materials.
- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4141, please consult the manufacturer's website or your local distributor.

By following these safety instructions, you help ensure a safe and effective experience with your TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4141. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk