

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4442

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4442](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020330
- Mfr. No.: 46542
- Delivery weight: 0.091kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 128mm
- UPC: 611760465420

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE
- About Us

Safety Instruction Guide for TOP PUNCHES

LYMAN/RCBS STYLE

Introduction

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE. This guide provides essential safety instructions and guidelines to ensure the safe use of this product. Please read this document carefully before using the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always inspect the product for any signs of damage or wear before use.
- Keep this product out of reach of children and vulnerable individuals.
- Follow all safety precautions when using tools and equipment.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform to stay informed.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when using the top punches.
- Use the product in a wellventilated area to minimize exposure to any potentially harmful fumes or dust.
- Ensure that the top punches are securely attached to the lubrisizer before use to prevent accidental detachment.
- Do not exceed the recommended pressure settings when using the top punches, as this may cause damage or injury.
- Avoid using the product if you are under the influence of drugs or alcohol.

Instructions for Installation and Usage

1. Installation:

- Ensure that the lubrisizer is unplugged and cool before installation.
- Select the appropriate top punch for your SAECO bullets.
- Align the top punch with the lubrisizer and insert it into the designated holder.
- Secure the top punch by tightening the locking mechanism until it is firmly in place.

2. Usage:

- Plug in the lubrisizer and turn it on.
- Adjust the pressure settings according to the manufacturer's recommendations.
- Feed the bullets into the lubrisizer while ensuring that they are properly aligned with the top punch.
- Monitor the process to ensure that the bullets are being lubricated evenly and correctly.
- Once the operation is complete, turn off the lubrisizer and unplug it before removing the top punch.

Disposal Instructions

- Dispose of any damaged or wornout top punches in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the TOP PUNCHES LYMAN/RCBS STYLE, please refer to the contact information provided with the product packaging or visit the manufacturer's website for additional support.

Thank you for your attention to these safety instructions. Your safety and satisfaction are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk