

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4526

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4526](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020333
- Mfr. No.: 46547
- Delivery weight: 0.05kg
- Shipping height: 5mm
- Shipping width: 76mm
- Shipping length: 114mm
- UPC: 611760465475

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4526
- About Us

Safety Instruction Guide for TOP PUNCHES

LYMAN/RCBS STYLE SAEKO TOP PUNCHES

LYMAN/RCBS TYPE #4526

Introduction

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4526. This product is designed for use with Lyman and RCBS Lubrisizers and SAEKO bullets. To ensure safe use and compliance with the EU General Product Safety Regulation (GPSR), please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when using this product.
- Do not exceed the recommended load or pressure specifications when using the top punches.
- Ensure that the top punches are securely attached to the Lubrisizer before operation.
- Avoid using the product in wet or damp conditions to prevent electrical hazards.
- Follow all manufacturer instructions regarding the operation and maintenance of your Lubrisizer.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Lubrisizer is unplugged and not in operation before installing the top punch.
- Select the appropriate top punch for your SAEKO bullet type.
- Align the top punch with the Lubrisizer's mounting point.
- Securely fasten the top punch using the provided locking mechanism.

2. Usage:

- Plug in the Lubrisizer and turn it on.
- Load the SAEKO bullets into the Lubrisizer as per the manufacturer's instructions.
- Operate the Lubrisizer according to the guidelines provided in its manual.
- Monitor the operation closely to ensure everything is functioning correctly.

Disposal Instructions

- Dispose of any damaged or worn top punches in accordance with local waste disposal regulations.
- Do not dispose of the product in household waste. Instead, take it to a designated recycling or disposal facility.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the product, please refer to the manufacturer's contact point provided with the product packaging.

By following these safety instructions, you can ensure a safe and effective experience with your TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4526. Thank you for prioritizing safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk