

TOP PUNCHES LYMAN/RCBS STYLE - SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4537

[Reloading](#) > [Bullet Casting](#) > [Top Punches](#)

Straight shank type top punches designed to fit the Lyman and RCBS Lubrisizers and SAEKO bullets.



Attributes

- Name: [SAEKO TOP PUNCHES LYMAN/RCBS TYPE #4537](#)
- Manufacturer: [SAEKO](#)
- Product no.: 100020334
- Mfr. No.: 46548
- Delivery weight: 0.068kg
- Shipping height: 10mm
- Shipping width: 76mm
- Shipping length: 128mm
- UPC: 611760465482

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES #4537
- About Us

Safety Instruction Guide for TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES #4537

Introduction

Thank you for choosing the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES #4537. This guide provides important safety information and instructions to ensure the safe and effective use of this product. Please read this guide carefully before using the product.

General Safety Guidelines

- Always use the product according to the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any damage before use. Do not use if damaged.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Check the EU's Safety Gate platform for any recall updates related to this product.

Specific Safety Precautions for Use

- Ensure the product is compatible with your Lyman or RCBS Lubrisizer before use.
- Use appropriate protective gear, such as gloves and safety glasses, when handling the product.
- Do not exceed the recommended load specifications for your Lubrisizer.
- Avoid using the product in wet or damp conditions to prevent electrical hazards.
- Store the product in a cool, dry place away from direct sunlight and extreme temperatures.

Instructions for Installation and Usage

1. Installation

- Ensure that your Lyman or RCBS Lubrisizer is unplugged and clean.
- Align the top punch with the Lubrisizer's mounting point.
- Secure the top punch by tightening the set screw or lock mechanism according to the manufacturer's specifications.

2. Usage

- Before using the top punch, ensure that the Lubrisizer is properly set up and adjusted for the specific bullet type.
- Load the bullet into the Lubrisizer according to the instructions provided with the Lubrisizer.
- Operate the Lubrisizer according to the manufacturer's guidelines, ensuring that the top punch is correctly aligned with the bullet.
- Monitor the process to ensure that the top punch is functioning correctly and that there are no obstructions.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, check for recycling options or designated disposal sites for tools and equipment.

Contact Information for Further Support

For any questions or concerns regarding the product or safety instructions, please consult your retailer or the manufacturer's customer support resources.

By following these guidelines, you can ensure the safe use of the TOP PUNCHES LYMAN/RCBS STYLE SAEKO TOP PUNCHES #4537. Thank you for your attention to safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk