


STRIKER SPRING - KE ARMS STRIKER SPRING

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pin Springs](#)

Aftermarket Glock striker spring. Made in the USA.



Attributes

- Name: [KE ARMS STRIKER SPRING](#)
- Manufacturer: [KE ARMS](#)
- Product no.: 100023132
- Mfr. No.: 1-50-25-004
- Model: 33,34,17,22,27,31,26,38,23,19,32
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 51mm
- Shipping length: 127mm

Item details

Made in USA

Table of Contents

- Startpage
- STRIKER SPRING KE ARMS STRIKER SPRING Safety Instructions
- About Us

STRIKER SPRING KE ARMS STRIKER SPRING

Safety Instructions

Introduction

Thank you for choosing the STRIKER SPRING KE ARMS STRIKER SPRING. This aftermarket Glock striker spring is designed for specific Glock models, ensuring reliable performance. Please read this safety instruction guide carefully to ensure safe use and compliance with EU safety regulations.

General Safety Guidelines

- Ensure that the product is used only for the intended purpose as specified by the manufacturer.
- Always handle the product with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use this striker spring with compatible Glock models: 17, 19, 22, 23, 34, 26, 27, 31, 32, 33, and 38.
- Do not attempt to modify or alter the striker spring in any way, as this may compromise safety and functionality.
- Ensure that the firearm is unloaded before installing or replacing the striker spring.
- Wear appropriate safety gear, such as eye protection, when handling firearms and related components.
- Be aware of your surroundings and ensure that you are in a safe environment when using or installing the product.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, such as a punch tool and a small hammer.

2. Installation Steps

- Remove the slide from the frame of the Glock.
- Locate the striker assembly within the slide.
- Carefully remove the existing striker spring using the punch tool.
- Replace it with the STRIKER SPRING KE ARMS STRIKER SPRING, ensuring it is seated correctly.
- Reassemble the slide and frame, ensuring all parts are securely in place.

3. Usage

- After installation, conduct a function check to ensure the firearm operates correctly with the new striker spring.
- If any issues arise, consult a qualified gunsmith or contact customer support for assistance.

Disposal Instructions

- Dispose of the product in accordance with local regulations concerning hazardous materials.
- Do not dispose of the product in regular household waste.
- Contact local waste management authorities for guidance on the proper disposal of firearm components.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the manufacturer's contact information provided with your product packaging. Ensure you have your product details ready for a more efficient support experience.

Conclusion

By following these safety instructions, you can ensure the safe use of the STRIKER SPRING KE ARMS STRIKER SPRING. Always prioritize safety and compliance with local laws and regulations. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk