

"VICTORY" TRIGGER FOR RUGER® MKIV - TANDEM CROSS

"VICTORY" TRIGGER FOR RUGER MKIV - BLACK

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Triggers](#)

Drop-In Upgrade For A Straight, Light Trigger Pull

The Tandemkross Victory Trigger for Ruger® MkIV™ is a lightweight, skeletonized, flat-faced trigger that allows the shooter to pull straight back and instantly know if you're pulling too far to the left or right. With its flat faced design, the Tandemkross Victory Trigger encourages shooters to place their finger lower on the trigger, increasing leverage and letting shooters take advantage of lower trigger pull weights.

- Flat faced for better control and feel
- Adjustable for pre-travel and over-travel
- Fits Ruger® MkIV™ Target/Hunter/Competition/Tactical/Standard
- Will NOT fit MkIV™ 22/45
- Aluminum trigger available in black or silver

The Tandemkross Victory Trigger comes with pre- and post-travel adjustment screws to allow each shooter to customize their trigger pull. Textured trigger face offers a no-slip grip in any condition.



Attributes

- Name: [TANDEM CROSS "VICTORY" TRIGGER FOR RUGER MKIV - BLACK](#)
- Manufacturer: [TANDEM CROSS](#)
- Product no.: 100023851
- Mfr. No.: TK24N0172BLK1
- Finish: Black
- Weapon type: Ruger
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 108mm
- UPC: 769498482988

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for the Tandemkross Victory Trigger for Ruger® MkIV™
- About Us

Safety Instruction Guide for the Tandemkross Victory Trigger for Ruger® MkIV™

Introduction

Thank you for choosing the Tandemkross Victory Trigger for Ruger® MkIV™. This guide provides important safety information and instructions to ensure the safe use and handling of your new trigger. Please read this manual carefully before installation and use.

General Safety Guidelines

- Always treat all firearms as if they are loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Ensure that the firearm is pointed in a safe direction at all times.
- Store the firearm and trigger in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your trigger and firearm for wear or damage.
- Follow all local laws and regulations regarding firearm use and modifications.
- Use the trigger only with compatible Ruger® MkIV™ models as specified.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded before installation or adjustment of the trigger.
- Do not modify or alter the trigger in any way beyond the provided adjustments.
- Be aware that the flatfaced design may require different finger placement to ensure proper control.
- Adjust the pretravel and overtravel settings carefully to avoid unintentional discharges.
- If you experience any issues with the trigger, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the old trigger according to the firearm's manual.
- Install the Tandemkross Victory Trigger by following these steps:
 - Align the trigger with the trigger housing.
 - Secure the trigger in place using the provided screws.
 - Adjust the pretravel and overtravel settings to your preference.

2. Usage

- Before shooting, ensure that you are familiar with the trigger's feel and operation.
- Practice dry firing in a safe environment to acclimate to the trigger's characteristics.
- When at the range, maintain focus on your finger placement and trigger control.
- After each use, inspect the trigger for any signs of wear or damage.

Disposal Instructions

- Dispose of the trigger and any associated packaging materials in accordance with local regulations.
- Ensure that the trigger is rendered unusable before disposal to prevent unauthorized use.

Contact Information for Further Support

For any questions or concerns regarding the Tandemkross Victory Trigger, please refer to the manufacturer's website or customer support resources.

Conclusion

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your Tandemkross Victory Trigger for Ruger® MkIV™. Always prioritize safety and responsible firearm handling. Thank you for your attention to these important safety practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk